


earfun

EarFun Air Pro 4

ANC Wireless Earbuds



BC



Qualcomm® aptX™
Adaptive

User Manual

1. EarFun Audio App

Download the EarFun Audio app for an enhanced experience.

- No Forced Registration. Easy to Use.
- Multi-Band Equalizer, Multipoint Devices Management.
- Customizable Touch Controls, Wind Noise Cancellation.
- Relaxed White Noise, LDAC Switch, In-Ear-Detection Switch.
- Firmware Update, Find Headphones, Game mode, and More.



EarFun Audio




Download on the
Google Play



Download on the
App Store

Please update your earbuds firmware to the latest version via the EarFun Audio App for the best user experience. If earbuds can't connect to the app, reinstall or update the app in the app store.

2. How to Fit



1. Choose the best-sized ear tip



2. Insert




3. Rotate

Note:

1. Please choose the suitable ear tip for the best sound and secure fit.
2. Select the left or right earbud and insert to the corresponding ear.
3. Rotate the earbud back and forth for the ear tip to create a comfortable seal.

3. Pair Your Earbuds

First-time pairing with device




Pair and connect two Bluetooth devices simultaneously

Option A


Easily set up in the Dual Device Connection of the EarFun Audio App.

Option B



4. In-Ear Detection

L/R



remove to pause



put back on to resume or
answer a call (not for VoIP call)





*Please turn off or on In-Ear Detection in the EarFun Audio app.

5. LDAC

How to activate and deactivate LDAC:


1. Ensure your Android supports LDAC. (iOS devices do not support LDAC.)
2. Install the EarFun Audio app and ensure the earbuds are connected to the app.
3. Go to the "Bluetooth Audio Quality" in app settings, turn the LDAC on or off, click "Sure" in the popup, and the earbuds will reboot with LDAC activated or deactivated.

6. Reset

- 1 
Put back in the case
- 2 
* White LED flash triple rapidly
Press for 8s
- 3 
Delete the previous Bluetooth record
- 4 
Reactivate Bluetooth to reconnect


7. Touch Controls

Playing music




Noise cancelling control

Noise cancelling
/Ambient sound
/Normal




Hands free conversation


Answer and
transfer two calls
Tap triple (L/R)



Activate the voice assistant

Voice assistant



 Game Mode : Please enable in EarFun Audio app

8. LED Indicator Guide

Earbuds Status


Power on	Turns on for 1s
Power off	Turns on for 1s
Pairing mode	Flashes
Successfully connected	Turns off
Factory reset	Flashes triple rapidly

White LED indicator
inside the charging case



Battery level

3 x White LED	60%-100%
2 x White LED	30%-60%
1 x White LED	10%-30%
1 x White LED Flash	<10% Please charge



White LED indicator
outside the charging case

Specifications

Bluetooth version	V5.4
Bluetooth frequency	2.402GHz-2.480GHz
Bluetooth profile	A2DP, AVRCP, HFP, HSP
Bluetooth transmitted power	<7dBm (for EU)
Battery capacity	54mAh x 2 (earbuds); 600mAh (charging case)
Charging time	1 hour (for earbuds) 2 hours (for charging case via USB-C) 3.5 hours (for charging case via wireless charger)
Playtime (varies by volume level and audio content)	ANC OFF -- Up to 11 hours. Totally 52 hours with the charging case; ANC ON -- Up to 7.5 hours. Totally 35 hours with the charging case;
Dimensions	62.4mm x 46.6mm x 29.2mm
Weight	56g

9. Troubleshooting

Q: The earbuds are turning on, but fail to connect to my device?

A: To connect your earbuds to your device, please remove the insulating films on the charging case and check that Bluetooth is enabled. If the earbuds still don't connect, try resetting them or contact us for assistance.

Q: What to do if one earbud is silent or has low volume?

A: If the earbud's LED is lit, carefully clean the dirt from the speak mesh using a toothpick or cotton swab dipped in alcohol. Try to reset the two earbuds and reconnect. If the issue persists, please contact us for assistance.

Q: How to resolve noise issues?

A: Please choose suitable ear tips, rotate earbuds for a snug fit. Note that slight background noise in quiet environments in ANC mode is normal for all kinds of ANC earbuds.

Q: What to do if the other person cannot hear clearly during a call?

A: Please adjust the position of the earbuds to ensure that the voice microphone is pointing towards the direction of the speaker's voice. Ensure the Bluetooth device uses the earbud's microphone for calls.

Q: What to do if the earbuds fail to connect to the app?

A: Ensure Bluetooth connection and Location permissions are enabled for the app. These permissions do not involve any privacy information. You can also download the latest version of the app or uninstall and reinstall it if needed.

Q: What to do if the audio quality does not meet your expectations?

A: We suggest personalizing your audio settings according to your preferences in the EarFun Audio app's EQ settings.

Q: Why is the connection not stable and cuts out intermittently?

A: Please check for any objects obstructing the earbuds and the Bluetooth device, and avoid any potential radio or Wi-Fi interference. While the earbuds have a maximum range of 49 feet (15m) without obstacles, the actual range may vary depending on usage and the environment.

Customer Service

For FAQs and more information:

Please send an email to: service@myearfun.com

www.myearfun.com