




Smart Battery Camera

Operation Instruction

Packing list


1. Camera*1
2. Bracket*1
3. Mounting kit*1
4. User Manual *1
5. USB charging cable *1
6. Solar Panel(for option)*1
7. Operation instruction*1




Customer Service:

pmg-aftersale@outlook.com

Product appearance





Quick start

The wireless smart battery camera operates on the built-in internal batteries and can also be powered

1. Download and install the App


The wireless smart battery camera supports Android and iOS devices using the mobile **APP**. For your best experience, please scan the QR code below with your mobile phone, install the **App**, and follow the instruction to complete the user registration.



Please use your phone's camera or Google Chrome to scan the QR code.
ATTENTION: Other methods or Apps may cause your privacy at risk.


2. Add the device

Sign in to App ,tap on the Green "+" symbol on the upper right corner the tap on " Add a New Camera " and follow the prompts displayed on screen (please bring the camera and device close to the router when initially configuring).



Set Up the Camera


Step 1) After pressing the camera switch for 3 seconds, the camera will turn on. The camera will emit the scanning sound "Ding Dong Ding Dong" after it is turned on (if you do not hear it, please quickly press the power button twice).




Step 2) Tap on the "Add Camera Now" button on the App and follow the on screen instructions for the Battery Camera by long pressing the power button on the bottom of the camera. Once you hear the camera chime please tap on the circle next to "I heard the sound or saw the light on", then tap on "Next Step".

Step 3) On the following page please confirm that you hear the camera emitting a beeping sound and tap on the circle next to "I heard a beeping sound" then tap on "Next Step".


Step 4) On the next page select your desired 2.4GHz WiFi network from the drop down menu under "WiFi Name (SSID)" then enter the password. To ensure a longer connection range, the camera only supports 2.4GHz WiFi with stronger wall penetration capability and does not currently support enterprise level authentication. Once complete please tap on "Next Step".



Step 2




Step 3




Step 4

Step 5) Point the lens of the camera at the QR code generated by the App about 7 inches away until you hear a "Ding" sound.




Step 6) After a few moments the camera will provide a prompt sound indicating that the connection was successful. At this point the App will request that you place the camera at the location you wish to set it up at (you do not need to mount it at this point). Please check the signal strength to ensure that it is adequate for this location then tap on "Next Step".




Bluetooth Set Up the Camera

1)Click the "Add Now" button in the app, press and hold the camera switch button for 3 seconds to turn on the camera, and the app will automatically search for devices that are on and not bound. Select the device you want to bind in the search results for the next step.



2)Enter the name and password of the Wi-Fi network you want the camera to connect to. To ensure long-distance connection, the camera only supports 2.4GHz WiFi network with stronger wall penetration capability and does not support Wi-Fi with enterprise-

level authentication. Please make sure that the Wi-Fi meets the requirements, click Next after completion, and the app can try to connect the camera to the Wi-Fi.



3)After a while, the camera will play a sound indicating that the connection is successful. At this point, please set a name for the camera on the app and select the location where you want to place the camera. Click Finish to complete the pairing.

! Wi-Fi connection troubleshooting:

24/7 customer service email: pmg aftersale@outlook.com

If you encounter any problems, please feel free to contact us.


- If you hear "**WiFi password error**" from the camera, please check whether the WiFi password you entered into the App is correct. The first letter of the password is automatically capitalized on some devices.
- If you hear "**WiFi not found**" please check whether your selected WiFi network has the correct name and make sure to place the camera as well as the device you installed the App on is near the router. Also make sure the network is broadcasting in 2.4GHz 5GHz is not supported.
- If you hear "**Authentication error**", please ensure that the WiFi network is not set up with enterprise level authentication as the device only supports security-levels of WPA-2 and below.
- If you hear "**Retrieving IP timeout**" this indicates that there are too many devices connected to your router and is unable to allocate additional space for the camera. Please remove some of your connected devices and restart the router before attempting to connect the camera again.
- If you hear "**Cloud service connection fail**" please make sure your router is properly connected to the external network, typically this is your modem connection. This error is usually caused by a network disconnection or your router is set up for local area connections only. Please check your network connectivity then attempt to connect the camera again.

Install the camera

You can place the camera on a shelf or other surfaces to use, or you can install it on a wall to use.

(1) Select a good spot for your camera

Select a good spot for your camera, please install the camera in a position where its view is not blocked and ensure that it is within the coverage of the Wi-Fi network. The PIR infrared sensor is more sensitive to movements across the camera's field of view than movements toward or away from the camera.



(2) Install the bracket


1) Screw fixing:

Use the drilling tool to punch holes on the wall according to the hole distance of the base. It is recommended to mark the holes on the wall with a pencil before drilling. Screw the expansion nut into the holes on the wall, and then connect the bracket to the expansion nut with screws to complete the fixing.



2) Fix the camera


Align the bracket screw with the screw hole on the back of the camera, and then rotate it to the tightened state.



3)Adjust the angle

Adjust the camera to an appropriate angle, the best angle is about 15 degrees downward, and then tighten the base by rotating it in clockwise direction to fix the angle.


About 15 ° downward




Share the camera

When you need to view the camera with other family members or friends, you can use this function. Only the administrator whose account is bound with the camera for the first time can share and set the device. Other members can only view the live or playbacks of the device.


1) Find the camera you want to share on the App homepage or camera setting page. Find the button and enter the sharing page.



- 2) Click "Invite", and a QR code will be generated for sharing.
- 3) For the members you need to share, find "Add Friend's Camera" in the "User" page to enter the scanning page.



4) Scan the QR code on your mobile phone, and you will receive the confirmation notification after success. The sharing will be completed after you agree.



Charge the camera

App will remind you to charge your camera when the battery is low. Please use the Micro USB cable to plug into the 5V/1.5A charging adapter to charge the camera. During charging, the camera's indicator light is solid yellow, and when the camera is fully charged, the indicator light will turn into solid green. It will take 10 hours to fully charge the camera.

Indicator light status

Mode	Status
Working mode	Blue
Sleep mode	Off
Charging mode	Yellow
Fully charged mode	Green

Product specification

Item	Specification
Camera lens	Field of view: 110°
Image resolution	Max. 1920×1080
Video bit rate	Adaptive
Storage media	Micro SD card (Up to 128GB)
Battery capacity	5000mAh
Adapter requirement	5V/1.5A
Size	70*59.2*90 (mm)

Firmware upgrade

When you connect your camera through the App, it will prompt you if the latest firmware is available. You can also manually check the firmware upgrade in the settings of the App.

- ❗ Please make sure that your camera is fully charged or connected to the power adapter before upgrading the firmware, please do not cut off the power supply during the upgrading.

FCC warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
 - (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FAQ

24/7 customer service email: pmg-aftersale@outlook.com

If you encounter any problems, please feel free to contact us.

1.Q:Camera permission management: How to invite family and friends to use my camera together?

A: Open the App and select your camera on the home page. Click the share button on the home page or the "Share" in the camera settings to enter the sharing page, and then click "Invite " to generate a QR code. Your friends can now get some of the access rights by scanning the QR code in your phone.

2.Q:Why doesn't the Wi-Fi name appear when I connect to Wi-Fi?

A: On Apple devices with iOS13 and above, you need to turn on the "location permission" for the app in the system settings and change it to "allow when using."

3. Q:Will the camera show red lights when night vision is activated?

A: The built-in infrared lamp beads make the camera only show some dim red lights when night vision is activated, but the image quality is still clear under no light environment.

4.Q:What are the requirements for Wi-Fi?

A: Please use a 2.4GHz wireless network. The device does not support the 5GHz wireless network. Meanwhile, please set the Wi-Fi authentication method to WPA2-PSK or other lower level of security method. A password is required.

5.Q:How far should the camera be placed from the router?

A: After testing, the Wi-Fi connection distance can normally reach up to 150 meters in the open area. However, the actual situation depends on the strength of Wi-Fi and its surrounding environment (thick walls, electromagnetic devices, large metal objects will all cause interference to the Wi-Fi signals). If the camera connection signal is weak or unstable, please place the camera as close to the router as possible.

6.Q:What is the maximum length of recording time?

A: VicoHome Awareness subscribed users: Maximum recording time up to 3 minutes if you set duration to " Auto " .

Unsubscribed users: The maximum length of recording time is 20 seconds.

7.Q:How to quickly view videos by category?

A: Click the icon in the upper left corner of the "Library" page to start filtering videos by category. Select the category you want to see and then click "Save" to view the video playbacks.

8.Q: What should I do when the device is in malfunction?

A: Long press the power bottom for 3 seconds to restart it. If there is no response, you can remove the rubber plug at the button of the camera. Press the reboot button to restart the camera while charging.

24/7 customer service email: pmg-aftersale@outlook.com

If you encounter any problems, please feel free to contact us.

