


Wake-up Light User Manual



Read and follow all instructions in this user manual before use.

Notice:


The CR2032 batteries only save the time of day and the programmed wake time. All functions are only possible with mains power operation.

ThreeDucksDirect@outlook.com

Contents

1.Product Information-----	01/02
2.Setting and Maintenance-----	03
3.Time Display Setting-----	04/05
4.Alarm Setting-----	06
(1) Switching the Alarm on/off	
(2) Alarm Setting - Alarm Day Setting	
5.Alarm Clock and Wake-up Light Setting-----	07/08
6.Snooze Function-----	09/10
7.FM Radio Operation-----	11/12
8.Relaxing Bedtime Sound Function-----	12
9.Wake-up Light Setting-----	13/14
(1) Light - Wake-up Light Mode	
(2) Light - Mood Light Mode	
(3) Light - RGB Mood Light Mode	
10.Fall Asleep Function-----	15
11.Time Display Brightness-----	16
12.Change Battery -----	16

Product Introduction



Front of product

Back of product

1. Snooze,+/- (Clock Time&Volume, Alarm clock Time&Sound& Volume&Light Intensity Adjustment), FM Radio Manual Searching
2. Alarm 1 on/off button/Alarm 1 Setting
3. Alarm 1 on/off button/Alarm 2 Setting

ThreeDucksDirect@outlook.com

4. Time Display Brightness/Time Setting
5. Radio on/off Button/FM Radio Automatic scanning
6. Relaxing Bedtime Sounds on/off/sound change Button
7. Radio Volume Increase/Manual Station Selection
8. Radio Volume Decrease/Manual Station Selection
9. Fall Asleep Function
10. Wake up light/Mood light on/off /color change Button
11. RGB Mood Light on/off/color change Button
12. Increase Light Intensity
13. Reduce Light Intensity
14. Every Day/Weekday/Weekend Mode for Alarm1
15. Every Day/Weekday/Weekend Mode for Alarm2
16. Battery Compartment
17. USB Charging Port
18. DC Charging Port

ThreeDucksDirect@outlook.com

Setting and Maintenance

First use

Connect the AC adapter to the power jack of Wake-up Light and plug the AC adapter into a household socket with 100-240V. And place the Wake-up Light 40-50cm from your head, for example on a bedside table.

Install battery


Wake-up Light is pre-installed with a CR2032 battery, please remove the insulating sticker for normal use.

Storage

Wake-up Light should be placed into the carton or stored at a cool and dry place.

Cleaning

Wipe dust off with a soft and damp cloth. Please do NOT use liquid or abrasive cleaners.




Time Display Setting

The default clock time is AM 12:00 when you plug in the appliance for the first time.

Notice: The following operation should be operated step by step.

1. Hour Time Setting



Press and hold the time set button  for at least 2S to start hour setting after the time display is on, the hour indicator in the display blink, then rotate the + and - on SNOOZE button  to changes by one hour, press the time set button  to confirm and the minute indicator in the display blink at the same time.



2. Minute Time Setting

Rotate the + and - on snooze button  to changes by one minute after the minute indicator in the display blink, press the time set button  to confirm and start to set 12-hour(AM/PM) or 24-hour clock mode at the same time.



ThreeDucksDirect@outlook.com

3. Adjusting 12-hour(AM/PM) or 24-hour Clock Time

Rotate the + and - on SNOOZE button  to choose between a 12-hour(AM/PM) and a 24-hour clock, press the time set button  to confirm and start to set what day is today.

4. MON - SUN Setting

Rotate the + and- on snooze button  to choose what day is today after its icon in the display blink, then press the time set button  to choose a day from MON to SUN and complete all the time setting.

Notice: The time of day will revert back to AM 12:00 o'clock if the device is disconnected from the mains power supply with no back-up batteries inserted or if the back-up batteries are too weak or if insulating sticker do not be removed.

ThreeDucksDirect@outlook.com

Alarm Setting - Switching the Alarm on/of

Prerequisite: The time display is ON.


Press alarm 1  or alarm 2  if you want to switch the alarm on or off. The corresponding icon appears on the display when you switch on the alarm. It disappears when you switch off the alarm.

Notice: The operation modes of alarm 1 and alarm 2 are exactly the same.

Alarm Setting - Alarm Day Setting

Prerequisite: The alarm1 icon or alarm2 icon appears on the display.


Set, with the  ¹⁴ switch or  ¹⁵ switch, every day/weekday/weekend modes are available for alarm1 and alarm2, slide the switch to adjust the daily alarm as shown in the following picture:



ThreeDucksDirect@outlook.com

Alarm Clock and Wake-up Light Setting

Notice: The following operation should be operated step by step.



1. Alarm Hour Time Setting

Press and hold the  for at least 2S after the time display is on, the hour indicator in the display starts to flash, then rotate the + and - on snooze button  to changes by one hour, press the  to confirm and the minute indicator in the display blink at the same time.

2. Alarm Minute Time Setting

Rotate the + and - on snooze button  to changes by one minute after the minute indicator in the display starts to flash, press the  to confirm and start to set wake-up sound at the same time.

3. Wake-up Sound Setting

Rotate the + and - on snooze button  to choose a wake-up sound from S01 to S08 and OFF, press the  to confirm and start to set alarm volume.

ThreeDucksDirect@outlook.com

Notice: You can use wake-up sounds or the FM radio as a wake-up Sound. The Wake-up Light built-in 7 wake-up sounds (S01 - S07), S08 is FM radio. The corresponding icon appears on the display when you choose one.

4. Alarm Volume Setting

Rotate the + and - on snooze button  to adjust the volume from V01 to V16 (16 levels in total), then press the  to confirm and start to set wake-up light intensity.

5. Wake-up Light Intensity Setting

Rotate the + and - on snooze button  to adjust the wake-up light intensity from L01 to L20, press the  to confirm and start to set the dawn duration time of the wake-up light.

Notice: The screen displays show OFF, L01 - L20 in turn. You can choose OFF if you don't need light, while L20 chosen means light intensity increases gradually from L01 to L20.

6. Dawn Duration Time of Wake-up Light

The dawn duration time is the time in which the light intensity of the lamp gradually increases to the set level before the alarm sound is played.

The range of dawn duration time of the wake-up light is 10-60MIN, the dawn duration time can be changed by 10 minutes to your preference by rotating the + or – on snooze button  , press the  to confirm and complete all the alarm clock and wake-up light profile setting.

Note: You can not select Wake-up Sound and Wake-up Light to be "OFF" at the same time.

Snooze Function

The wake-up light turns on at the set time after alarm 1 or alarm2 activated, the light intensity increases to the set maximum light intensity before the alarm sound is played. The following operations are available when alarm sound is played, you can operate according to your requirement:

1.Snooze

You can press the button  to snooze for a while. The wake-up light and the alarm sound stop. After 9 minutes, the lamp turns on and the alarm sound is automatically played again. (User Tip: The number of snoozes is unlimited.)

2. Manually stop the alarm

There're 2 ways to stop the alarm

(1) Press the alarm1  or alarm2  if you want to turn off the current wake-up light and alarm sound when the alarm sound is played or the alarm is snoozed.

(2)When the alarm goes off, holding the snooze button  for 3 seconds to turn off the alarm for the day.

3. Automatically stop the alarm

If there is no operation within 20 mins, the alarm will automatically turn off.

Note:

- 1.The alarm 1 or alarm 2 icon flashes on the display when the alarm is snoozed.
- 2.The alarm 1 or alarm 2 icon stays bright on the display, which means alarm 1 or alarm2 activated.

FM Radio Operation

To get a great radio performance, we recommend making the wire antenna un-coiled completely. And when the radio is working, please adjust the antenna position to get the best reception effect.

Notice: The following operations should be operated step by step.

1.Switching on/off the radio

Press the FM on/off button  to switch on/off the FM radio after the time display is on.

2.FM automatic scanning

To scan radio frequencies automatically when the time display is on, press and hold the  button for 2 seconds and the device will scan for all available stations from 76.0 MHz to 108.0 MHz. When the scan is complete, the device will play the first available station.

3.Manual station selection

After FM automatic scanning has been completed from 76MHz to 108.0MHz, then press and hold down the  /  button for 2S to adjust the last/next radio station.

4.Adjust the FM Radio Volume

Click the button  /  to increase or decrease the radio volume after the radio display icon is on.station.

5.FM Radio Manual Searching

Rotate the + and – on SNOOZE button  to manually adjust the FM frequency to change by 0.1MHZ after the radio display icon is on.

Relaxing Bedtime Sound Function

1.Switching on the relaxing bedtime sound function

Press the button  to switch on the relaxing bedtime sound function after the time display is on and the relaxing bedtime sound icon appears on the display. Then click the button  to change sounds from S01 to S08, and click the  /  to adjust the sound volume.

2.Two ways to switch off the relaxing bedtime sound function

(1)The relaxing bedtime sound function has 8 sounds: S01-S08, it will be turn off if you click button  again when S08 sound set, the relaxing bedtime sound icon disappears from the display.

(2)To switch off the relaxing bedtime sound function, press and hold down the  button for 2 seconds. The relaxing bedtime sound icon disappears from the display.

The appliance has 3 light modes: wake-up light, mood light and RGB mood light. Please make sure the device is connected with the mains power supply and the time display is on before you are ready to do the following operations:

Light - Wake-up Light Mode

1. Press the button  to switch on the wake-up light and use it as a bedside light.
2. You can adjust the light intensity by pressing the + and – buttons  /  .
20 levels of brightness adjustable
3. To switch off the wake-up light, press the button  again.

Light - Mood Light Mode

1. Press and hold the button  for at least 2S on the device to switch on the mood lighting.
2. Click the button  to change the color of mood lighting. The LEDs light up in the following sequence: red → orange → yellow → green → blue → indigo → purple → etc.

3.You can adjust the mood light intensity by pressing the + and – buttons

 /  . 10 levels of brightness adjustable

4.To switch off the mood light, press and hold the button  for at least 2S again.

Light - RGB Mood Light Mode

1.Press the button  to switch on the RGB mood light and use it as a mood light too.

2.Click the button  to change the color of RGB mood lighting from C01 to C07. There are 7 different RGB lighting colors in total.

3.You can adjust the RGB mood light intensity by pressing the + and– buttons

 /  . 10 levels of brightness adjustable

4.To switch off the RGB mood light, press and hold the button  for at least 2S.

Fall Asleep Function


Notice: The following operation should be operated step by step.

1. Press the fall asleep button  to switch on the fall asleep function after the time display is on.
2. The set fall asleep time appears on the display and flash for 5 seconds.
3. Rotate the + or – on the Snooze button  to adjust the time (10 to 120, 180 or 240 minutes).
4. You can set the desired light (3 light modes are available) and/or FM radio, or light (3 light modes are available) and/or the relaxing bedtime sounds when you want the light and/or FM radio, or the light and/or the sound of the Wake-up Light to stay on during a set period of time (10 to 120, 180 or 240 minutes) before you go to sleep. The FM radio, lamp and/or sound switch off automatically after the set time.
5. You can track your remaining bedtime by clicking the button  after the fall asleep function activated.
6. To switch off the fall asleep function, press and hold the fall asleep button  for at least 2 seconds. The fall asleep icon disappears from the display

Time Display Brightness

You are able to control the brightness of the clock's display manually according to your preferences. For example, you can change the brightness of the display so that intense light won't wake you in the morning. There are 3 brightness level, click the button  to adjust it after the time display is on. The time display turns off if you click the button  once more when the time display brightness is at the maximum brightness .

Change Battery



Remove the screw from the battery case with a screwdriver; insert the battery into the battery case, while the positive electrode is upward; insert the cover of battery case into the slot of battery case at the left side; tighten the battery case.

Contact us

If you have any using problems with the product, please don't be hesitant to contact us, we will be happy to help you solve various product problems so that you can get a better experience with products.

ThreeDucksDirect@outlook.com

For a lifetime-warranty, please contact
ThreeDucksDirect@outlook.com with your Amazon
Order Number to register product warranty.

JALL[®]

CUSTOMER SUPPORT

ThreeDucksDirect@outlook.com