

# Time Timer<sup>®</sup>

Visual Timer With Multiple Durations

# MAX

User Guide



**Includes:**

- 1 timer with 8 duration settings
- 3 two-sided timer faces  
(5/15 min, 30/60 min, 2 hr/dry erase face)
- 3 set markers
- 1 bracket mount






EN: Download these instructions in other languages.  
 NL: Download deze instructies in andere talen.  
 DE: Laden Sie diese Anleitungen in anderen Sprachen herunter.  
 FR: Télécharger ces instructions dans d'autres langues.  
 ES: Descargue estas instrucciones en otros idiomas.  
 JA: その他の言語の取扱説明書は、以下のQRコードからダウンロードできます。  
 KO: 이 안내서를 다른 언어로 다운로드하세요.




## 1 Install Batteries




Open the battery door. Insert two C batteries.

## 2 Set Timer




Turn counterclockwise to set timer.  
Disk disappears clockwise. When the disk is gone, time is up.

## 3 Set Alert




Red switch:  
Choose volume settings (high, low or no sound).

## 4 Set Time Duration



Turn the time duration dial to *match* the total length of time represented on the selected timer face or written on dry erase face.

## 5 Insert Timer Face



Insert your finger through the hole on the back of MAX and push out all three two-sided timer faces. Place the selected timer face (or dry erase face) on the top and then snap them back in place, one face at a time.

Additional timer faces available at [timetimer.com/maxfaces](http://timetimer.com/maxfaces)


## 6 Dry Erase Face Option



You can also use the dry erase face with any time duration to set routines. Draw pictures to separate time blocks by activity. Example: reading, math, writing, snack time.

## 7 Using Set Markers

Extra set markers available at [timetimer.com/setmarkers](http://timetimer.com/setmarkers)




Create time blocks on any face by snapping set markers in the grooves between the red disk and numbers.

## 8 Kickstand Position




Pull out the kickstand to set the device upright on any surface.

## 9 Hanging Position



Flip the kickstand over the top of the MAX to hang from a whiteboard hook or map rail.

## 10 Bracket Wall Mount



Attach bracket to wall with screws, making sure it is level. Slide the open slot on back of MAX over mounted wall bracket.

## 11 Screw Wall Mount



A small notch on the back of the timer allows you to hang MAX from a screw on the wall. Leave a gap between the screw head and the wall for the timer to hang on.



## 5 Bright Ideas for Dry Erase Faces and Set Markers

Dividing the time *within* the red disk is great for routines of all kinds!



**Classroom routines** for all ages. Teachers can visually reinforce when it's time to switch from reading to math or from group work to independent study.



**Stay on track by marking start times for each agenda item.**



**Interval training.** Know exactly when to switch from push-ups to rest to squats.



**Empower kids** and adults with special needs. **Ease transitions** by marking several on the timer face.



**Morning routines** for kids. Divide up those 30 minutes into getting dressed, brushing teeth, combing hair and putting on shoes.

See the iconic red disk, know it's a Time Timer.

### Supercharge your Time Timer MAX

Purchase extra timer faces and time set markers on our website.

Timer faces: [timetimer.com/maxfaces](http://timetimer.com/maxfaces)

Set markers: [timetimer.com/setmarkers](http://timetimer.com/setmarkers)

Make Every Moment Count!

[timetimer.com](http://timetimer.com)



Designed in the USA. Patent protected. Manufactured in China. 202207V12 TT72B-W  
Time Timer LLC • 7707 Carmargo Road, Cincinnati, OH 45243 • 877-771-TIME  
Support: [support@timetimer.com](mailto:support@timetimer.com) • More timers + accessories: [timetimer.com](http://timetimer.com)