


FRENCH PRESS COFFEE MAKER

User Manual




How to Brew the Perfect Coffee?

1. Place the French press on a dry, flat, non-slip surface. Hold the handle firmly, then pull the plunger unit straight up and out of the pot.




2. Pour hot (not boiling) water into the pot to warm the French press. Pour the water out of the French press after a minute.



3. Add coarsely ground coffee into the pot. For an 8-ounce cup, 1 to 2 scoops of coarsely ground coffee is recommended.

CAUTION: Use only coarsely ground coffee. Fine grounds (such as espresso) may block the filters and create high pressure during operation.



4. Place the French press at a 45-degree angle. Slowly add hot water (about 203°F/ 95°C) to the pot. Do not completely fill the pot; leave at least 1 inch of space.




5. Stir the brew gently with a spoon to make sure the water and grounds are fully mixed.


CAUTION: Metal spoons can scratch or chip the glass beaker and cause breakage.



6. Attach the plunger unit to the pot. Turn the lid to close the pour spout. Let the coffee brew for at least 4 minutes.




7. Hold the handle firmly and turn the spout away from you. Apply force to the top of the knob to push the plunger straightly down to the pot. Press the plunger slowly and steadily with minimal pressure to make sure you get the best taste.



WARNING: If the filter is stuck or the plunger is difficult to push down. You should remove the plunger from the pot, stir the brew, and slowly try to push the plunger down again. Using excessive force can cause scalding liquid to splatter out of the pot.

8. Turn the lid to open the pour spout and then pour coffee into a cup.



Coffee Mixture

Add the water quantity relative to the grounds, as shown below:


Amount of grounds	Water
0.5-0.7 Oz / 15-20 g	~10 Oz / ~300 mL
0.6-0.9 Oz / 18-27 g	~15 Oz / ~450 mL
0.8-1.2 Oz / 24-36 g	~20 Oz / ~600 mL
1.0-1.6 Oz / 30-45 g	~25 Oz / ~750 mL
1.4-2.0 Oz / 40-60 g	~34 Oz / ~1000 mL

What Makes Our French Press Stand Out?

1. Durable material: 304 stainless steel.
2. Borosilicate glass: heat resistant up to 392°F.
3. Safe food grade material.
4. Precise scale on the glass pot.

Cleaning Tips:

1. Unscrew the filter assembly and clean the plunger unit after each use. All parts are dishwasher safe.
2. Clean gently with bottle brush or sponge.
3. Always use neutral detergent.
4. Dry all parts before assembly.



Warnings:

 Do not use glass beaker if it has scratches, cracks or chips. Please check before use.



HOT

Hot coffee and knob. Allow the coffee to cool before drinking.



SCALD ALERT

Pressing too fast or with force of more than 15lbs can cause scalding.



DO NOT USE ON AN ELECTRIC COOKER OR GAS STOVE.



KEEP AWAY FROM CHILDREN

WARRANTY INFORMATION

TWO YEAR NON-TRANSFERRABLE LIMITED WARRANTY

To provide customers with quality shopping and user experience, we guarantee to replace or issue a refund or provide acceptable solutions to any defective products (as customers prefer) from the date of purchase to 2 years.

Proof of purchase must be provided (order number or receipt) when making a claim to our customer support center.

**Warranty registration may be requested within a month since the date of purchase, by sending your product order number to the mailbox:
support@aborderproducts.com**

The warranty is not transferrable. We only provide warranty services to buyers who purchased from our store and possess the purchase proof, and not to any other purchaser or subsequent owner.

Price matching policy is not applicable.
No price difference refund.

Sellers are the responsible party. Platform allows different sellers to sell the same product, so please confirm the seller by checking the order details before contacting us.

WHAT IS COVERED

1. Received defective or used (proof needed) products;
2. Received with missing parts;
3. Defective item under proper use.

WHAT IS NOT COVERED

1. Purchased from **other platform channel** or **other physical stores**;
2. Gift without proof of purchase;
3. Tampering/ abnormal use/ accidental damage or commercial use;
4. Replacements and parts.
5. Installation fee/ labor fee.

MAKING A CLAIM

If you have any problems when using our products, you can choose any of the methods to reach out to us.

MANUFACTURER SUPPORT

Email: support@aborderproducts.com (24/7)




30 Days Free
Return & Replacement



2-Year Product Warranty

Have a question for the seller



① Find your order



② Click "View order details"



③ Click the "seller name"



④ Click "Ask a question"

Gifted parts, replacements, consumable products are not covered by the 2-year warranty. Manufacturers' warranties may not apply in all cases, depending on factors such as use of the product, where the product was purchased, or who you purchased the product from. Please review the warranty carefully, and contact the manufacturer if you have any questions.



MADE IN CHINA