

Problem	Possible Cause	Solution
Feed too hot after recommended cooling time	Rapid Cool was not fully reset	Allow Rapid Cool to reset after each use or heat-based cleaning/sterilization
Digital lid showing amber	Feed needs more time to cool	Wait recommended cooling time
Digital lid showing green immediately after filling flask with freshly boiled water	Built-in thermometer has not adjusted to milk temperature	Invert flask to keep milk in contact with thermometer to allow correct temperature reading. Always wait recommended cooling times before dispensing feed.
Digital lid showing green but feed too hot	Built-in thermometer has not adjusted to milk temperature	Invert flask to keep milk in contact with thermometer to allow correct temperature reading. Always wait recommended cooling times before dispensing feed.