# Model 50515 MaxxHaul 6,500 Lb. 6-1/4" Lift Car Ramps, 2-pack

### **Specification:**

Model	50515
Maximum Weight capacity	6,500 lbs. per pair
	3,250 lbs. per ramp
Maximum Lift Height	6-1/4"
Maximum Tire Width	12"

## **Important Safety Information**

- 1. ALWAYS READ THESE WARNINGS BEFORE USING RAMPS, STUDY, UNDERSTAND, AND FOLLOW ALL WARNINGS.
- 2. FAILURE TO READ OR FOLLOW THESE WARNINGS CAN RESULT IN DEATH, INJURY OR PROPERTY DAMAGE.
- 3. THIS IS NOT A TOY. DO NOT LET CHILDREN PLAY WITH RAMPS OR NEAR THE RAMPS.
- 4. **DO NOT** exceed the recommended weight limit of 3,250 lbs. per individual, 6,500 lbs. per pair, or 13,000 lbs. Vehicle Gross Weight.
- 5. ONLY USE ON HARD LEVEL SURFACE CAPABLE OF SUSTAINING THE LOAD.
- 6. Use on anything other than flat, hard surfaces could lead to injury, death, or property damage.
- 7. **PLEASE CENTER LOAD** between ramp's sides. Place ramp inclines tightly and in the middle of either the L&R front or L&R rear wheels.
- 8. Ramps must align with the vehicle and have their wheels pointing directly forward.
- 9. To support either the front or rear end of a vehicle, **USE ONLY AS MATCHED PAIR**.
- 10. INSPECT AND ASSESS RAMPS PRIOR TO EACH USE. If broken or damaged, DO NOT USE.
- 11. Each ramp should have rubber feet, and debris and oil should be removed from the ramps. If worn or damaged, destroy and throw away.
- 12. The driver of the vehicle should be observed and directed as they go up and down the ramps by a second person who is standing clear from vehicle path.
- 13. Ramps ARE NOT TO BE USED TO SUPPORT A VEHICLE ON ONE SIDE OR BOTH ENDS AT THE SAME TIME.
- 14. **NOT INTENDED** for storage on the incline of the ramps. Please **DO NOT** use as a leveling device.
- 15. Use on vehicles with MAXIMUM **12-INCH** TIRE WIDTH.
- 16. The ramps ARE NOT TO BE USED IN CONJUNCTION WITH OTHER LIFTING EQUIPMENT.
- 17. While the car is on the ramps, DO NOT disconnect the brakes, the engine, the gearbox, the drive train, the drive shaft, the universal joints, or the wheels.
- 18. **NEVER SUDDENLY ACCELERATE OR APPLY THE BRAKES.** Move carefully and slowly.
- 19. Only use the brakes to prevent overtravel once the car has reached the top of the ramps.
- 20. When climbing, braking could cause ramps to slide or tip.
- 21. RAMPS SHOULD NOT BE USED ON SLIPPERY OR SLICK SURFACE.
- 22. Put the car in neutral and release the brakes when the tires touch down in the cradle section

of the ramps.

#### 23. THE VEHICLE SHOULD NOT MOVE. ENABLE OR SET EMERGENCY BRAKE.

- 24. Put the car in park (or in reverse gear for manual transmissions). Chock wheel on ground.
- 25. Make sure the support structure for the ramp is level and that both tires are positioned correctly.
- 26. Shake the vehicle sideways and endways to check that the vehicle and ramps are stable, practice caution to keep your body away from any potential hazards and danger.
- 27. Verify that the ramps were not damaged or bent during loading.
- 28. Use only the attachments and/or adapters that the manufacturer provided.
- 29. If a ramp appears to have been subjected to an abnormal load or shock, inspect immediately for damage.

#### 30. DO NOT MODIFY RAMPS.

- 31. Before the use of this product is permitted, the operator must receive this warning in the operator's native language.
- 32. Make sure the operator is fully aware of the risks connected to the proper usage and misuse of these ramps.
- 33. Remove from service until it is evident whether there is any uncertainty regarding the correct and safe usage of this product. **SEEK ASSISTANCE FROM PROFESSIONALS OR TRAINED INDIVIDUALS IF UNSURE HOW TO PROPERLY USE THE RAMPS.**
- 34. These warnings must be followed in the maintenance of the ramps.
- 35. Do not remove this warning.
- 36. It is advised that an annual examination be performed by trained individuals, and that any broken parts replaced or discarded and/or warning labels be replaced.
- 37. RATING CAPACITY OF 3,250 lbs. Per pc, 6,500 lbs. per pair, and 13,000 lbs. GROSS VEHICLE WEIGHT.
- 38. Maxx Group, LLC is not responsible for the attachment or the installation of the ramps.

#### **Limited Warranty**

Maxx Group LLC strives to ensure that its products maintain high standards of quality and durability. We guarantee to the original purchaser that our product is free from defects in materials and workmanship for a period of 90 days from the date of purchase. This warranty does not cover damage resulting directly or indirectly from misuse, abuse, negligence, accidents, unauthorized repairs or alterations, criminal activity, improper installation, normal wear and tear, or lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states may not permit the exclusion or limitation of incidental or consequential damages, so these limitations may not apply to you.

This warranty is the sole warranty provided, replacing all other warranties, whether express or implied, including but not limited to the warranties of merchantability and fitness. To avail of this warranty, the product or part must be returned to us with prepaid transportation charges. Proof of purchase date and a description of the issue must accompany the return. If our inspection confirms the defect, we will either repair or replace the product at our discretion. If a replacement cannot be readily provided, we may opt to refund the purchase price. We cover the return shipping costs for repaired products. However, if we find no defect or if the defect falls outside the scope of our warranty, you are responsible for the return shipping costs.

This warranty grants you specific legal rights, and you may also have additional rights that vary depending on your state's laws.

Manufactured and Distributed by: Maxx Group, LLC, Camarillo, CA 93012, USA www.maxxhaul.com