

## CLEANING AND DISINFECTING YOUR BATH SPA

- 1) Your Bath Spa can be cleaned with any mild detergent or soap. Cleaning is recommended after each use.
- 2) Disinfect your unit periodically to keep it bacteria free. With frequent use, disinfect weekly. With infrequent use, disinfect after each use.

## RECOMMENDED MASSAGING TIMES

Spa massage should generally last only 15–20 minutes.

**Caution:** Read safety rules and operating instructions carefully. This product is intended for indoor use on permanent, right-wall tubs. Do not use outdoors or on the walls of inflatable tubs or pools.

## HOW TO ATTACH YOUR BATH SPA TO YOUR TUB

- 1) Make sure the power knob is in the OFF position. The tub should be clean and empty of water.
- 2) Extend the folding arm and position unit along edge of tub so the unit is inside the tub and the arm is resting on edge (Fig. 3).
- 3) Moisten suction cups on motor housing of Bath Spa to increase grip.
- 4) Secure suction cups by gently applying even pressure on Bath Spa against tub wall (Fig. 3).
- 5) Adjust suction cup on arm so that it adheres directly onto bathtub edge. See Fig. 4 and Suction Cup Position Adjustment section following (Fig. 6).
- 6) Adjust height of motor assembly to desired depth by moving motor housing up or down by hand. Built-in detentes will hold the position you desire (Fig. 5).
- 7) Water may spray if unit is not level when turned on.



Fig. 3




Fig. 4



Fig. 5

## SUCTION CUP POSITION ADJUSTMENT

Suction cup underneath the handle can be in 1 of 2 positions to suit different bathtubs. (See Fig. 6)

Push and slide the suction cup to the desired position.

**Position A:** The outermost position for thick-sided tubs.

**Position B:** The innermost position for thin-sided tubs.

Fig. 6

