
How to Operate



Clean drum assembly thoroughly.




Place drum on pulley coupler. Gently rotate till drum fixes itself.



Place the roller stone assembly in the drum in position as indicated above.




Close the arm and press gently to lock automatically.



Pour 200ml of water into the drum.



Press the switch downwards to turn on the appliance.




Add the grinding medium in small quantities with adequate water and place the hatch.




When required consistency is achieved, switch off the appliance.



Remove hatch, hold the arm and press lock to release, then swing the arm upwards and rest it suitably



Remove roller stone assembly and wipe down the batter.



Remove the drum and use required amount of batter. The rest can be stored in your refrigerator.

How to Use Attachment



Remove Roller Stones assembly and place the atta kneader in the drum. Lock the arm and feed **approx 250 gms** of atta through the opening provided. Pour a little water and switch on the appliance. Add little oil and salt to taste. Add water drop by drop till you get the required consistency.