

MODEL NO. 73303

T3 Micro
Gardena, CA USA
Made in China

WWW.T3MICRO.COM



UG-73303r1

T3 WARRANTY TERMS & CONDITIONS

T3 Micro will repair or replace (at our option) T3 products for twenty-four (24) months from the date of purchase if they are defective in workmanship or materials.

This warranty does not cover: (1) damage during installation or (2) tampering, such as repair or attempted repair. To obtain service under the warranty, please call 1888.340.8880 or email us at info@T3micro.com to obtain a Return Authorization Number as well as explicit instructions on how to return the defective product. You will be required to return the defective product with a proof of purchase, a check made out to T3 Micro, Inc. for \$14.95 for shipping and handling, and a brief description of the product's deficiencies. Please clearly mark the Return Authorization Number on the outer packaging when sending us the defective item.

THIS LIMITED WARRANTY IS ONLY VALID: (1) IF PRODUCT IS REGISTERED WITH T3 MICRO WITHIN 21 DAYS OF PURCHASE; (2) IF PRODUCT IS PURCHASED FROM AN AUTHORIZED SELLER OF T3 GOODS.

Any implied warranties, obligations, or liabilities, including but not limited to the implied warranty of merchantability and fitness for a particular purpose, shall be limited in duration to the 24 month duration of this written limited warranty. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

Visit www.T3micro.com/register to complete your warranty registration.

PERFORMANCE DATA

Rated Service Flow – Maximum 2.5 gallons per minute / 9.5 liters per minute

Rated Service Life at 75% free chlorine removal – 3,000 gal / 11,356 liters

Maximum working pressure – 80 pounds per square inch / 552 kilo pascals

Maximum operating temperature – 120°F / 49°C

Notes:

Tested under standard laboratory conditions. Actual performance may vary. Filtration system not intended to be used as a drinking water treatment unit. System and installation must comply with applicable state and local regulations.



Hand-Held User Guide

T3 Source Shower Filter

CHLORINE FILTRATION HAND-HELD UNIT
Model No. 73303

INSTALLATION INSTRUCTIONS: T3 Source Shower Filter HAND-HELD Model Number 73303

You will need


- 1 inch open end wrench or adjustable crescent wrench

Installation Procedure


1 Unscrew existing showerhead from pipe. Clean the threads. Wrap plumber's tape (included in box) clockwise around pipe threads.

2 Screw shower arm bracket onto shower pipe.


3 Attach one end of hose to bracket and the other end to shower handle.



4 Place T3 Source Hand-Held into its shower arm bracket. Flush with hot water for 5 minutes before showering.



Recommended:
For optimal performance, reverse the filter inside the T3 Source Hand-Held every month.




TIP

If your showerhead is difficult to remove, try the following:

1. Soak joint area with vinegar to break down calcium deposits and/or wrap a wet, hot towel around area to loosen joints.
2. Grasp the pipe with a crescent wrench and unscrew the showerhead with a pipe wrench. Use caution so as not to cause damage.

HOW TO USE YOUR: T3 Source Shower Filter HAND-HELD Model Number 73303



MAINTENANCE INSTRUCTIONS: T3 Source Shower Filter HAND-HELD Model Number 73303

Filter Replacement

Purchase replacement filter online from the retailer where you purchased this unit or visit www.T3Micro.com. For optimal performance, your filter should be replaced every 3-4 months or when the filter replacement indicator turns black.

Order Filter Number: 73306

For your convenience, a static cling has been included in this package. Simply fill in the filter replacement date and apply to a smooth surface for a convenient reminder.

Filter Installation Procedure

1. To unlock shower handle, grasp bottom half, turn counter-clockwise until 2 dots meet and pull apart from top half
2. Remove used filter and recycle by puncturing screen and emptying contents into garden or flushing down drain
3. Recycle plastic container
4. Remove seal from each end of new filter
5. Lightly lubricate O-rings at each end with Vaseline®
6. Push new filter firmly into handle base until it clicks into place
7. Push handle base firmly into top half, aligning 2 dots, and twist the bottom half clockwise back into position
8. Flush with hot water for a full 5 minutes before showering

Tip: Reverse the filter every month for best results.