

Thank you for purchasing the tape dispenser
For smooth operation and safety reasons,
please read the instructions carefully and comply with it for usage.

HOW TO USE

1. Hold the DEVICE firmly with single hand;
2. Press down the LEVER at full length with all 4 fingers, tape comes out at about 30mm in length instantly ;
3. Point the DEVICE to the applied surface (flat & smooth preferably) till the tape can touch and stick on it;
4. Pull back the DEVICE as long as the desired length comes out;
5. Release the LEVER by holding back all 4 fingers instantly so that the tape is cut automatically.

NOTES TO USE


1. The tape comes out automatically at about 30-40mm if you press down and release the LEVER at the same time. If longer tape length is required, press down the LEVER, pull back the DEVICE as long as the desired length comes out.
2. The DEVICE is designed to have 5mm uneven cutting on tape after each stroke. It results that the cut tape does not fall down on floor accidentally.
3. The DEVICE can use 2 different tape sizes, 19mm or 12mm in width. Suitable tape thickness is 0.05 -- 0.07mm. 3M Scotch Tape is highly recommended.
4. For best performance of each stroke, press down the LEVER at full length (not at half way) and then release instantly, otherwise tape jam occurs easily.
5. Make sure the front-end opening of the DEVICE is cleared off after each stroke. otherwise tape jam occurs easily.
6. If tape is jammed inside, open the cover, take out the tape and remove residues. Then install the tape again properly.

SPECIFICATION :


Dimension (WxLxH)	38mm X 168mm X 94mm
Weight(g)	135
Tape Roll max	12mm X 20M or 19mm X 33M
Ambient Temperature	-18°C to 49°C

Patent Number
China 201010100011.9
Japan 5184585
Japan 3162506
Germany 2527278.0


HOW TO INSTALL TAPE




1. Press lock and open the transparent cover. Take out the roller.




2. Install the proper tape on the roller. Place it back into the rail.




3. Pull the tape at length 30 - 40mm so that the tip can rest easily on the row of the rubber bands.



4. Replace the transparent cover.



5. Press down the LEVER to initialize and load the tape into the front-end opening.



6. Click and Go.