



UV / LED LAMP

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

DANGER - To reduce the risk of electrocution:

- 1 Always unplug this appliance immediately after using.
- 2 Do not place or store appliance where it can fall or be pulled into a tub or sink.
- 3 Do not use while bathing.
- 4 Do not place in or drop into water or other liquid.
- 5 Do not reach for an appliance that has fallen into water. Unplug immediately.

WARNING - To reduce the risk of burns, electrocution, fire, or injury to persons:

- 1 An appliance should never be left unattended when plugged in.
- 2 Close supervision is necessary when the appliance is used by, on, or near children or invalids.
- 3 Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- 4 Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water. Return the appliance to a service center for examination and repair.
- 5 Keep the cord away from heated surfaces.
- 6 Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- 7 Never drop or insert any object into any opening.
- 8 Do not use outdoors or operate where aerosol (spray) products are being used.
- 9 **WARNING:** Do not expose the skin to UVLED lamp for more than 10 minutes.
- 10 Individuals can't reuse in one day.

SAVE THESE INSTRUCTIONS

PRODUCT MANUAL

SAFETY WARNING

- 1 Please read through this User Manual carefully and keep it properly.
- 2 Please make sure the input voltage meets the requirements of the product.
- 3 Keep away from water or high humidity.
- 4 Do not allow debris or any types of liquid into the product, or a malfunction may occur.
- 5 When timer doesn't work, stop using the product.
- 6 A damaged adapter must be replaced to avoid risk. Please contact your dealer regarding this matter.
- 7 Please apply neutral detergent for cleansing purposes. Make sure it is turned off and unplugged. Do not use remover or other acidic detergent to wipe.
- 8 Do not keep the machine working continuously for over 600s, otherwise it may reduce its lifespan.
- 9 It is recommended that curing time for base gel and color gel should not exceed 60s, and that of top coat should not exceed 90s.
- 10 Do not use gels that are not compatible with the product.
- 11 Apply proper maintenance may extend the lifespan.
- 12 Not suitable for people who are sensitive to UV, under certain medication or who require special care.
- 13 When not in use, please unplug.

01 ITEM CHECKLIST

- Lamp
- Adapter
- User Manual
- Bottom Plate

02 PARTS INTRODUCTION

- 1 Infrared Sensor
- 2 On/Off Button
- 3 5s Timer
- 4 30s Timer
- 5 60s Timer
- 6 Port




03 PRODUCT INTRODUCTION

- 1 The UVLED lamp is designed for both professional manicurists and amateurs, to cure UV, builder and LED gels.

04 HOW TO USE

- 1 Connecting adapter to host first, then plug adapter into outlet.
- 2 Press the On/Off button to turn on the lamp, and it lasts for 90s. Press again to turn it off.



- 3 Press ON/OFF button for 2s, and the power will switch over.
- 4 After the lamp is turned on, press the related button (5s, 30s, 60s), this initiates the curing windows accordingly.
- 5 You may also trigger the infrared sensor to turn on the lamp by putting your fingers under the lamp. The default process lasts for 90s.

05 TECHINCAL PARAMETERS

- 1 30 LED beads
- 2 Lamp input voltage: DC24V/1.2A (Powered by an external adapter)
- 3 Adapter parameters: Rated input: 100-240Vac 50/60Hz 1A
Rated output: DC24V/1.2A
- 4 Size: 150mm x 190mm x 85mm
- 5 Wave length: 365nm+405nm
- 6 Working Temperature: -10~+40°C; Working Humidity: 10%-90%RH
- 7 Storage Temperature: -20~+60°C; Storage Humidity: 5%-95%RH
- 8 Working Atmosphere: 86~106kPa

06 WARNINGS

- 1 Please use proper gels that are compatible with the product.
- 2 This product is not suitable for children, pregnant women or skin cancer patients.
- 3 Reduce skin exposure to the UV light, and do not stare at the UV light.
- 4 Do not overuse the product. Avoid eye exposure to the UV lights to prevent retinal damage.
- 5 It is recommended that you wear sunscreen before the cure.
- 6 Do not take any medication that triggers UV allergy. When in doubt, please consult with your physician.
- 7 If any discomfort occurs (e.g. rashes, pain) after the cure, please seek medical attention immediately.



Implementation of standards: Q/YCHC 001- 2016

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.