

5. Installation of Mirror 02

P1: Mirror with cold shoe can be mounted on the ring light via cold shoe mount.
 P2: Display Effect after Mounting the Mirror.




6. Installation of Smartphone

P1: Place the ball head on the ring light cold shoe female base and screw it tightly.
 P2: Put the smart phone in place.
 P3: Align the 1/4" thread hole at the bottom of phone holder with the 1/4" screw on the ball head and screw them tightly.
 P4: Turn on the remote controller as well as the phone Bluetooth, then find "AB Shutter 3" at Bluetooth interface.




7. Installation of Tablets

P1: Loosen the buckles on the back of tablet bracket, adjust and place the tablet on the bracket.
 P2: Align the 1/4" thread hole at the bottom of tablet bracket with the 1/4" screw on the ball head and screw them tightly.
 P3: Turn on the remote controller as well as the tablet Bluetooth, then find "AB Shutter 3" at Bluetooth interface.



Applications



1. Perfect Selfie Gadget


Stable Light and hands free operation.

2. Delicate Personal Makeup and Filming Makeup Tutorials for Youtube

Create a flat, even lighting that diminishes texture and shadow.

3. Excellent Helper for Photographers

Create stellar, fashion infused images with even soft lighting effect.



NEEWER[®]
 Pro Quality Amateur Prices



EN

Neewer Customer Support
www.neewer.com

Related Accessories

Note: The accessories mentioned in this Manual are only served as demonstration of the ring light installation. Different Ring light models should be matched with different accessories. Please check the PACKAGE CONTENTS on the listing page before ordering and purchase other proper accessories separately if you need.




Installation Guide

1. Installation of Light Stand

P1: Folding State
 P2: Hold the middle pole of light stand with one hand and draw out the stand legs with the other hand.
 P3: Adjust the stand legs to the angle you want.




P4: Loosen the screw on the middle pole, extend the light stand to the height you want.
 P5: Tighten the screws again.



2. Installation of Soft Tube

P1: Loosen the screw at the end of the soft tube, attach it to the top of light stand and tighten the screw again.
 P2: Loosen the screw at the bottom of the ring light base, attach the ring light to the soft tube, and tighten the screw again to secure the ring light.
 P3: To achieve different photography effects, soft tube can be bent over to some degree to help you freely adjust the angle of the ring light.



3. Installation of Color Filter

P1: First, mount the color filter at the bottom of the ring light (The unique filter)
 P2: Then, mount the other three color filter in order.
 P3: Display Effect of Color Filters.



4. Installation of Mirror 01

P1: Place the semicircle mirror to the inner side of the ring light by aligning their screw holes.
 P2: Display Effect after Mounting the Mirror.

