

TROUBLESHOOTING

BREWER DOES NOT HAVE POWER

- Plug brewer into an independent outlet.
 - Check to be sure that it is plugged in securely.
 - Plug into a different outlet.
 - Reset your home's circuit breaker, if necessary.
 - Make sure that the Power Button has been turned on and the green Power Light is illuminated.
-

BREWER WILL NOT BREW

- After placing the K-Cup® pod in the K-Cup® Pod Holder, make sure that the Handle is pushed down securely and the blue Brew Buttons are flashing.
 - If the blue Add Water Light is illuminated, add water to Water Reservoir. Fill to and not beyond the MAX FILL line. Make sure the Water Reservoir is seated properly in its base.
 - If the blue Add Water Light continues to be illuminated even after refilling, contact Customer Service at 1.866.901.BREW (2739).
 - If the blue Add Water Light, red Heating Light, and Small Mug Button are all flashing simultaneously, see next situation.
-