

INSTRUCTIONS FOR USING

Wool dryer balls work by separating laundry in the dryer, allowing hot air to circulate more evenly and efficiently.

1. Grab wool dryer balls and simply toss them into the dryer with your laundry.
2. How many dryer balls should I use? For small or medium loads, use 2-4 balls, and for large loads, 5-6 balls. If you want to save even more time, add a few extra wool dryer balls.
3. Turn on the dryer and monitor your laundry for the first few loads. Please note: Over-drying clothes isn't ideal. Clothes that are too dry may increase electrostatic. Minimize drying time to prevent electrostatic adhesion. When using them for the first time, they may shed some wool, which is natural, and this will diminish after washing or repeated use.
4. You should replace wool dryer balls approximately every 1,000 loads.
5. Option: Allow the essential oil to soak into the dryer balls for 10-20 minutes before use. The more oils absorbed into the dryer balls prior to use, the more slowly they will disperse in the dryer, and the slower, the better!