

Belt Adjustment

>If your Treadbelt tends to walk to the right, use your tool, included in the hardware kit, to rotate the right side six angle screw counterclockwise one or two rotations.

>If your Treadbelt tends to walk to the left, use your tool to rotate the left side six angle screw clockwise one or two rotations.

>If your Treadbelt is too tight, rotate the both six angle screws (right and left) counterclockwise.

>If your Treadbelt is too loose, rotate the both six angle screws (right and left) clockwise.

Belt Alignment

During transportation, the belt may have shifted to one side. Carefully tip the unit to one side and check to see that the walking belt is resting on the two guide hooks welded under the frame. If you find that the belt has indeed shifted, simply pull the belt toward the center of the unit, lift up on the belt, and reposition it so that it is once again resting on the guide hooks.

