

What should I do if my Kasa device keep losing connection or going Offline?

Troubleshooting

Updated 03-05-2024 01:32:06 AM

 195592

This Article Applies to: 

There are some circumstances in that Kasa smart devices do not work stably or lost connection from time to time, this could be due to the network environment or some other reasons, this article provides some helpful tips to fix the situation.

Step 1 Ensure Router is working properly. Reboot the router and kasa device and see if the smart device reconnects.

Step2 Ensure Kasa smart device is receiving a Good Wi-Fi signal by checking RSSI (Received Signal Strength Indicator)

Kasa APP->tap  in the left top> **Device Settings**->**Device info** ->tap **Wi-Fi** icon to see signal strength (the value of RSSI)


Strong: more than **-50 dBm**

Good to Average: among **-70 dBm** to **-50 dBm**

Poor: less than **-70 dBm**

Note: If RSSI is less than -70dBm, the signal is too weak, device disconnections are likely, relocate the smart device or router to get a stronger Wi-Fi signal.

Chat Now



Step 3. Update the firmware of the Kasa device

Step 4. Ensure Kasa APP is up-to-date in the APP store or Google Play

Step 5. Turn off Advanced Wi-Fi settings on the router like **Band Steering** (also called '**Smart Connect**' or '**Whole-Home Wi-Fi**'), Wi-Fi Optimizing or 'Channel optimization' etc.

Step6. [Optional] Try to configure the smart device to another router's 2.4G Wi-Fi or a mobile Hotspot Wi-Fi to verify whether this issue is related to the specific router.

If the issue is still the same, contact [TP-Link technical support](https://www.tp-link.com/us/support/faq/3434/) and provide the information below for our support to look into further:

1. Led status on a smart device when it is offline: Red/ Flashing Green/ Solid Green etc. (For Kasa plug)
2. MAC address of the device
3. TP-Link ID email address
4. When an issue occurs, does the smart device work in **the local network**?

For a test, connect your mobile device to the home Wi-Fi network at that time and see if the Kasa device is still accessible in the local network.

...ne model number Wi-Fi router and your network topology:

Chat Now

e.g. ISP Spectrum-Archer C7 router<Wireless> Kasa device

6. How often does the issue happen, and how does recover the connection, like rebooting the smart plug or rebooting the router?

Is this faq useful?

Your feedback helps improve this site.

Yes

No

Recommend Products



KL125

Kasa Smart Light Bulb, Multicolour



HS103P3

Kasa Smart Wi-Fi Plug Lite



HS220-LA

Kasa Smart Wi-Fi Light Switch,
Dimmer



TP-Link Community

Still need help? Search for answers, ask questions, and get help from TP-Link experts and other users around the world.

[Visit the Community >](#)

Subscribe

Be The First To Get Exclusive Deals & News

Email Address

Subscribe

Let's Connect

Chat Now

About

- About Us
- Corporate Information
- Contact Us
- Sustainability
- Privacy Policy
- Your Privacy Choices
- Careers at TP-Link
- Accessibility
- Our Security Commitment

Press

- News
- Blog
- Security Advisory
- Security News
- Awards

Partners

- Partner Program
- Partner Deal Registration
- MAP Policy

Learning Center

- Technology Trends
- Training & Certification

Promotions

©2026 TP-Link Systems Inc. and its affiliated companies. All rights reserved.

United States / English

TP-Link, Tapo, Kasa, Omada, VIGI, Aginet, HomeShield, and Tapo Care branded products are products of TP-Link Systems Inc. or its affiliates.
Note: Some services and materials may require you to accept additional terms and conditions before access or use.
References to "TP-Link" may include TP-Link Systems Inc., its subsidiaries, or business units within the TP-Link corporate structure, as applicable.
The materials provided, including but not limited to press releases, presentations, blog posts, and webcasts, are current as of the date of publication and may be superseded by subsequent updates.

Chat Now