

# Alarm Clock Instructions



Can't charger phone no longer, send wrong color or any other problems, pls contact us On Amazon or by email for a new replacement.

Our email : nicetwo'clock@outlook.com

## Important:


If nothing shows on the display when plugged in , please slide the knob toward

“ +” Knob:  -



If you find the clock fails to remember settings. It may be the memory battery has run out of its power. You can replace CR2032 battery to recover its memory function.

## Wireless charging:

<p>①</p> 	<p>Plug in 5V 2A power adapter with the clock. Adapter comes with package. You can also use your 5V 2A phone adapter instead.</p> <p>However, please understand DO NOT use 5V 1A adapter because its power not enough for wireless charging. ( Need 5V 2A or above)</p> <p>Place your wireless phone on the correct charging area. Make sure your phone case is NOT thicker than 5mm.</p>
<p>Compatible moldes:</p> <ul style="list-style-type: none"><li>- iPhone 8, iphone X and newer generations.</li><li>- Samsung Note9、 S9、 S9+、 Note8、 S8、 S8+、 S7 Edge、 S7 and other newer generations.</li><li>- any other phones that supports wireless charging may be compatible with.</li></ul> <p><b>Attention: Do not put anything in the phone case when you use wireless charging.</b></p>	
<p>② Incorrect position e.g.1</p> 	<p>③ Incorrect position e.g.1</p> 
<p>④ Incorrect position e.g.3</p> <p>Magnetic steel siece</p> 	<p>Warning</p> <p>Please remove the magnetic steel piece while the phone is charging. If there is a magnet steel piece in the phone case, it will cause the charging device and the phone to become very hot.</p> 

## Setting:


### 1. Brightness Setting

- ① In the normal display mode, slide the knob to adjust the brightness.
- ② Slide the knob to '+' to increase the brightness, and to '-' to decrease the brightness.
- ③ Brightness range. (0%-100%)

### 2.12 /24 Setting

Press "12/24" button to select 24-hour or 12-hour display mode(default 12-hour clock).  
When 12-hour clock is selected, the AM or PM icon will be displayed.


### 3. Time Setting




① Press the 'TIME' button to enter the time setting menu, and then slide the knob to select the year.



② After selecting the correct "year", press the 'TIME' button to confirm and next




③ Slide the knob to select the correct "Month" Value and "Date" value, press the 'TIME' button to confirm and next (picture above means July,1)



It's 8pm now


④ Slide the knob to select the "Time", press the 'TIME' button to confirm . Time setting finished. Attention: to exit setting mode ,stop pressing for 10 secs,and it will return to time display automatically

### 4. Alarm Clock Setting(Same setting method for AL1 andAL2)



① Press the 'AL1' button to enter the AL1 alarm clock setting menu.

Alarm indicating light appear if alarm turn on



Alarm time: 8:01 pm

② Slide the knob to select correct “ Alarm Time” of AL1. Press “AL1”button to confirm. (pay attention to the AM and PM, If it is 12-hour mode )

### 5. Alarm Switch Setting

- ① OFF: Turn off alarm clock
- ② MON-FRI: Alarm clock is on when it is Weekday(Monday-Friday)
- ③ ON: Alarm clock is on everyday

### 6. Volume Adjustment Setting

- ① Press the ‘VOL’ button to enter the volume setting menu, and then slide the knob to adjust the Volume.
- ② Slide the knob to ‘+’ to increase the volume, and to ‘-’ to decrease the volume.
- ③ Press “VOL” button to confirm setting .

### 7. Temperature Setting

Press the “ °C/°F ” button to switch the °C(Celsius) or °F (Fahrenheit)

### 8. Snooze Function

- ① When the alarm rings, press any button to get 9-minute snooze.
- ② If you want to end the alarm clock, please press any button two times.
- ③ The alarm symbol will flash after the alarm enters snooze mode.

### 9. Reset

Use a needle or little stick to push the “RESET” hole to reset all settings.

### 10. Warranty

We offer 90days money back guarantee and 366 days free replacement.  
If you product have any problem.