

Thank you for your purchase.

Ready to install a powerful, quiet, reliable, and safe heater? **Say hello to the Alpha Heater 2024!**

This powerful heater fits into any space, from an office to the kitchen, and everything in between.

Alpha Heater can quickly heat a small to medium-sized room (up to 350 square feet) and includes safety features like overheat protection and a sleep timer for automatic shut off. It's easily programmable and comes with a remote, so you can change the temperature from anywhere in the room.



#### Temperature is displayed in Celsius.

Max Heat is 32 Degrees Celsius which is 90 Degrees Fahrenheit.  
Minimum heat is 15 Degrees Celsius which is 60 Degrees Fahrenheit.

The Alpha Heater runs on Celsius, and the temperature spans from a minimum of 15 degrees Celsius (60 degrees Fahrenheit) all the way up to 32 degrees Celsius (90 degrees Fahrenheit). Please note that setting the heater to the highest temperature may trigger the overheat safety feature; at which point, the unit will shut off.

# Product Specifications and Description

<b>Model Number</b>	HEAT-V2
<b>Model Name</b>	Alpha Heater
<b>UPC</b>	850058961002
<b>Voltage</b>	120 Volts (AC)
<b>Amperage Unit</b>	2.9 Amps
<b>Mounting Type</b>	Wall Mount
<b>Heat Output</b>	450 Watts
<b>Height x Width x Depth</b>	6.5" x 4.3" x 2.8"
<b>Heating Coverage</b>	350 Square Feet in minutes
<b>Weight</b>	14 ounces
<b>Power Source</b>	Electric and Plug-in (no cords)
<b>Temperature</b>	Displayed in Celsius (max 32 degrees)

## Getting Started

Here are a few quick steps on how to use the Alpha Heater:

### Step 1) Preparing the Unit

After you unbox the heater, you should find the following:

- The Alpha Heater unit
- Remote control
- Instruction manual

The heater should always be placed with at least 50 cm of free space around it.

The heater should be plugged into a correctly functioning, 110-125 V/50 Hz socket, with the power switched off (0 pushed in). It's best to find an outlet that's free from any obstructions.

## Step 2) Powering the Heater On

Facing the unit, the main power switch is on the right side. Make sure you set the main switch to I (on).

The heater is now on standby, and the LED screen should light up with two dashes. Press the power button on the lower, left-hand side to start blowing hot air.

## Step 3) Increasing or Decreasing the Temperature

After you hit the power switch, the LED screen will light up with the temperature (**in Celsius**). If you are accustomed to Fahrenheit, then 73 degrees Fahrenheit is equivalent to 22 degrees Celsius.

You can adjust the temperature setting with the two top buttons that look like thermometers. The (+) will increase the heat, and the (-) will decrease it.

## Step 4) Adjusting the Fan Speed

There are two fan speeds. If you want to adjust the fan speed to blow faster or slower, press the two temperature control buttons at the same time. The LED screen will flash either **LL** for low or **HH** for high.

Whatever setting you choose will blink four times before the screen goes back to the temperature reading.

## Step 5) Setting the Sleep Function

The timer button, (looks like a clock) on the bottom right, is what you use to set the number of hours before the heater auto shuts off. Click this until you reach the number of hours you want to run the heater. The sleep function can be set for up to **12 hours**.

For example, if you are in the office for 8 hours a day, you may want to click the timer button until it hits 8. This means the heater will run as you set it, for the next 8 hours, then shut itself off automatically. This is a built-in safety feature that offers advanced protection.

## Step 6) Powering the Heater Off

When you are ready to shut the heater off manually, simply press the power button once. The heater will begin a countdown on the LED screen for 60 seconds, blowing cold air to cool the unit down.

**\*\*It should also be noted that the heater has overheat protection. That means, if it gets too hot, the unit will shut off automatically.**

# Things to Know

## Changing the Position of the Heater

Under the plug on the back of the unit is a square button that will help you adjust the setting of the heater. Press and hold the adjustment button, then turn the plug. This allows you to use the unit in both vertical and horizontal ways.



## Using the Remote Control

The remote has the same buttons as the heater and responds the same way. This enables you to change the temperature from a distance, without the need to touch the unit itself.

## FAQs

### What if the Heater Falls Over?

In the event the heater falls forward, switch it off and unplug the unit for 5 minutes.

This will allow it to cool down before plugging it back in. Be careful not to directly touch the front grill, as to avoid injury or burns.

## **How Many Watts Does the Heater Use?**

The Alpha Heater uses 650 Watts on low, and 1200 Watts on high.

## **How Large of an Area Will It Heat?**

The Alpha Heater is designed to safely heat areas up to 350 square feet. That means your space will be nice and toasty!

## **What if My Heater Doesn't Stay Plugged In?**

Press and hold the adjustment button under the plug and switch the setting of the heater to horizontal. Now it will sit sideways, but the weight will be dispersed differently. Many people also consider using an extension cord or power strip.

If you position the unit sideways, and the heater is still not secured, your sockets may not be UL-certified. The weight of the unit is specifically designed to be supported by modern sockets.

## **Can I Plug my Heater into an International Adapter?**

It is not recommended that you plug the heater into any adapter.

## **Is the Heater Safe Around Kids and Pets?**

As long as the appropriate amount of caution and care is taken, the heater is safe to use around kids and pets. Just make sure the heater has completely cooled down before touching the surface.

## **How Far Away Should I Keep It from Furniture and Appliances?**

Leave at least a foot of space, and always keep the area directly in front of the heater clear.

## **Will This Heater Raise My Electric Bill?**

No, the Alpha Heater is considered energy efficient. It uses the same amount of energy as a standard hair dryer. So, say your electric company charges 10 cents per kilowatt-hour, then it would cost 12 cents per hour to operate.

## **Safety Instructions**

- The appliance can get warm, very quickly. Keep it away from children and pets at all times. Do not move the heater until it has cooled down.

- To prevent a fire, do not cover the air intake, as it will affect air circulation. This means it shouldn't be leaned up against walls or surfaces.
- Unplug the heater when it is not being used, and do not leave it unattended. Make sure to shut it off before you go to bed at night.
- Do not cover the heater with a blanket or towel, as this will cause the unit to overheat.
- Maintain a distance from the heater when it is in use to avoid burns or personal injury.
- The heater is intended for indoor use only and should be kept away from all heated surfaces.
- This appliance is only designed for the US with AC power. Prior to turning it on, ensure the voltage grid corresponds to what's required.
- Do not get the unit wet or touch it with a wet hand.

## Overheated Protection

The heater will automatically shut off when overheated, protect your house all the time. 



## Cleaning and Maintenance

From time to time, the front grill of the heater may collect dust and will need to be cleaned. Otherwise, the unit will start to overheat.

Always allow the heater to cool down and switch it to the "off" position, before maintenance. Here are a few steps to ensure the life of your Alpha Heater:

1. Wipe the outside of the heater with a damp cloth. Do not spray directly onto the unit or use aggressive chemicals.
2. Use a vacuum cleaner to carefully remove any dirt and dust from the grill. This ensures better air intake and less chances of overheating.
3. When the heater is not being used, store it in the upright position in a cool, dry, and dust-free area. You can save the original box for this!

\*It's important to note that the heater must be disposed of at your local authority's collection point for electrical appliances. You should not simply throw it away.

## Dear Customer:

Your satisfaction is important to us. If you have any questions about this manual or how to use the Alpha Heater, please reach out to us via Amazon messaging! Thank you once again for purchasing the Alpha Heater, and we look forward to your future business.

Be sure to check out our entire line of consumer electronics in the Amazon Alpha Heater store!

