





7. Microphone 8. LED Indicator Light 9. MFB/Mute Button 10. USB-C Charging Port

B. Donale Connection 1. Wireless Connection: BT 3. Wireless Frequency Band: 2.4 GHz 4. Supported Protocols: HSP, HFP, A2DP, AVRCP

1. Plug the dongle into the USB port of your computer. 2. Power on the headset and it will pair with your computer automatically.

Switching to Unilateral Headset

- 1. Press and hold the Release Button and pull out the Detachable
- 2. Snap the Detachable Head Clamp into the slot to use the headset as a unilateral one.

To Pair with Two Phones

- 1. Follow the above pairing guide to connect the headset to phone A, then switch off the Bluetooth function of phone A.
- 2 At this point, the headset automatically enters pairing mode 3. Search and click to connect to "TK-HS005" on the Bluetooth list of
- 4 After the headset is naired with phone B switch on the Bluetooth function of phone A and tap "TK-HS005" to reconnect to the headset. Now the headset is connected with two phones.

When the headset is paired with two phones, music can only be played from one. If you want to play music on the other connected phone, pause or stop playing the music on the previous one. If you want to answer a new call from the other connected phone, hang up the current call on the previous one.

EN-04

Operations Instructions

Button Function

Press and hold the MFB for 1 second oice assistant to activate the voice assistant on your phone. During a call, press and hold the MFB Audio for 2 seconds to switch between the switching headset and phone speaker. Button Mute/Unmute Short press the MFB to mute or the Mic unmute the Microphone. Press and hold the MFB and Volume – for 5 seconds to clear the pair record Clear pair in the headset. When it is cleared, the record headset will not be automatically reconnected and you need to establish connection again.

Operation Instructions

Power on Press and hold the MER for 2 seconds

Power off Press and hold the MFB for 3 seconds

Button Function Operation Instructions Press and hold the MFB and connec Charge reset the charging cable to charge the headset. This operation resets and reboots the headset. When playing music, double click the EQ mode MFB to choose from Pop mode, Bass mode, or Vocal mode. Play/Pause Short press the Phone Button to play/pause music. Answer a call Short press the Phone Button to answer an incoming call. Volume + Hang up a call Short press the Phone Button to hang up a call. Button Reject a call Press and hold the Phone Button for 1 second to reject an incoming call. Charging the Headset Redial a call Double press the Phone Button to dial the last number dialed.

To answer a new call and hang up the

Call waiting | current call, short press the Phone

EN-06

Button Function Operation Instructions current call, double press the Phone Button. To keep the current call and reject the Call waiting new call, press and hold the Phone Button for 2 seconds. To alternate between callers, double nress the Phone Rutton Press the Volume + button. (When the Volume Up volume reaches top level, you will hear a "beep" sound.) Next Song Press and hold Volume + for 1 second. Volume Down | Press the Volume - button. Previous Song Press and hold Volume - for 1 second.

- 1. When the LED indicator flashes RED, please charge the headset. 2. Connect the USB-C end of the charging cable to the headset and the
- USB-A end to a booted PC, charger, or power bank. The LED indicator lights in steady RFD

EN-07

- 3. Charging is completed in about 2 hours. The LED indicator lights in steady BLUE when the headset is fully charged.

- 1. When the headset will not be used for a long haul, charge it at least once every 2 months.
- 2. It is not recommended to use the headset while charging. 3. When the battery voltage is lower than 3.3V, you will hear "Battery Low" once every 3 minutes.

LED Indicator Light

Mode	LED Indicator Light
Power on	Blue Light flashes twice
Power off	Red Light flashes twice
Pairing mode	Red & Blue Light flash alternately
Connected standby mode	Blue Light flashes once every 10 seconds
Playing Music	Blue Light flashes once every 10 seconds
Talking	Blue Light flashes once every 10 seconds
Delete pair record	Blue and Red LED light up for 1 second
Link Loss (out of range)	Blue Light flashes once every 10 seconds
Low battery	Red Light flashes
	EN-08

LED Indicator Light Charging Steady Red Light Fully charged Steady Blue Light Incoming Call Blue LED flashes

Thank you for purchasing TECKNET Wireless Headset Please read this

uture reference. If you have any problem using this Wireless Headset,

User Manual thoroughly before use of the product and retain it for

please contact us by email at support@tecknetonline.com.

Voice Prompt

Status	Voice Prompt
Power on	Power on Power on
Pairing mode	Pairing
Pair success	Paired
Headset connecte	d Your headset is connected
Headset disconne	cted Your headset is disconnected
Low battery	Battery Low
Power off	Power off
Mute the Mic	Mute on
Unmute the Mic	Mute off
Pop Mode	Pop Mode
Bass Mode	Bass Mode
Vocal Mode	Vocal Mode

O: Can I use the headset while it is recharging?

A: Yes, but extremely low battery or poor power quality may cause electrical noise. We do not recommend frequent use in this way as it will shorten the battery life.

English ----- 01 - 15

Q: How to reconnect the headset and what to do when it fails to

- A: 1. When TK-HS005 is paired with your device successfully, it will reconnect to the paired device automatically within 10 minutes every time it powers on. If the reconnection failed, please try pairing again. It will power off if reconnection failed over 10
- 2. When the headset goes out of operation range, you will hear "Your headset is disconnected". It will reconnect automatically after entering the operation range.
- 3. To avoid reconnection failure, keep the headset away from electromagnetic interference devices such as microwave ovens,

Q: What's the password for pairing?

A: Some devices may require a password for pairing. Try entering 0000, 8888, 1111, or 1234.

EN-10

Q: What devices can recharge the headset?

A: Any charger, car charger, power bank, PC, etc. with DC 5V/above

A: Please try charge reset. Press and hold the MFB and connect the charging cable to charge the headset. After the charge reset, if the charging cable is not disconnected, the headset will reboot and

Q: What to do if I cannot turn the power on?

Q: What to do if I fail to pair the headset with my devices?

- A: 1. Power off the headset. Disconnect and connect the USB dongle again, then power on the headset. 2. Try charge reset.
- 3. If the above methods do not help, you may contact our customer service for more support.

Q: Why does the headset power off automatically?

A: When the headset is not connected over 10 minutes or the battery is too low, the headset will power off automatically.

EN-11

Limited 12-Month warranty

What this warranty covers.

*MFB: Multifunction Button

Shenzhen Unichain Technology Co., LTD. (Manufacturer: "Unichain") warrants to the original purchaser of this TECKNET product that the product shall be free of defects in design, assembly, material, or

What the period of coverage is.

EN-02

Unichain warrants the TECKNET product for 12 Months. What will we do to correct problems?

Unichain will renair or replace at its option, any defective product free of charge (except for shipping charges for the product). What is not covered by this warranty?

All above warranties are null and void if the TECKNET product is not provided to Unichain for inspection upon Unichain's request at the sole expense of the purchaser, or if Unichain determines that the TFCKNFT product has been improperly installed, altered in any way, or tampered with. The TECKNET Product Warranty does not protect against acts of God such as flood, earthquake, lightning, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (e.g. brownouts or sags), non-authorized program, or system equipment

modification or alteration. How to claim the warranty

Please contact retailers or visit TECKNET website or email **support@teck**netonline.com for more information. To extend the warranty period, please visit TECKNET website and register your TECKNET products within 90 days of purchase.

EN-12

2. BT Version: V5.0

7 Input: DC 5V-0 5A

8. Battery Voltage: 3.7V

Pairing Methods

will hear "Power on"

A. BT Pairing

5. Operation Range: 10 meters

6. Charging Time: approx. 2 hrs

9. Transmission Power: 3 dBm

1. Turn on the Bluetooth on your phone.

phone shows that "TK-HS005" is connected.

2. Press and hold the MFB for 2 seconds to power on the headset. You

3. Search and tap to connect to "TK-HS005" on the Bluetooth list of

your phone. Then you will hear "Paired. Your headset is connected."

The LED indicator will flash blue every 10 seconds after paired. The

The headset can also be connected to a computer by following the above

EN-03

Every effort has been made to ensure that the information and procedures in this guide are accurate and complete, no liability can be accepted for any errors or omissions and we reserve the right to make any changes without further notice to any products mentioned hereir

Correct Disposal of This Product

(Waste Electrical& Electronic Equipment) This Marking shown on the product or its literature, indicate that it should

not be disposed with other household wastes at the end of its working To prevent possible harm to the environment or human health from

uncontrolled waste disposal, please separate this from other types of material resources. Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe

Business users should contact their supplier and check the terms and conditions of the purchase contact. This product should not be mixed with other commercial wastes for disposal.

SIMPLIFIED EU DECLARATION OF CONFORMITY

Hereby, Shenzhen Unichain Technology Co., Ltd. declares that the product The full text of the EU declaration of conformity is available at the following internet address: https://eu.tecknetonline.com/

EN-13

Operation is subject to the following three conditions:

- (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
- (3) This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This equipment has been tested and found to comply with the limits for a

Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

which the receiver is connected. Consult the dealer or an experienced radio / TV technician for help.

Connect the equipment into an outlet on a circuit different from that to

IMPORTANT SAFETY INSTRUCTIONS-CAREFULLY FOLLOW THESE INSTRUCTIONS

1. RETAIN THESE INSTRUCTIONS - This sheet contains important safety and operatina instructions.

EN-05

2. Before using the product, read all instructions and caution markings on the product, accessories, and device. 3. Keep the product away from the fire to avoid an explosion.

4. Do not place the product in or near an inflammable, explosive, or hazardous object.

5. Do not operate the product with a damaged cord or plug. 6. Do not operate the product if it has been damaged in any way. 7. Do not disassemble the product. Disassembly may result in a risk of safety

8. Do not throw or shake the product.



EN-14

EN-15