

COOKING BARLEY

UNCOOKED GRAIN	LIQUID	MIN GRAIN	MAX GRAIN	COOKING TIME	FUNCTION
1 Part	2 Parts	1 Cup	2 Cups	5 Hours	Delay Timer & Brown Rice

1. Add desired amount of rinsed barley and a small amount of oil to the inner pot.
2. Fill the inner pot with the appropriate amount of liquid based on the ratio chart above.
3. Place the inner pot into the cooker.
4. Close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press the (⏻) button to turn on the cooker.
7. Press **Delay Timer**, and set for 4 hours. Then, press **Brown Rice**. The display will count down from the selected time
8. The cooker will now begin cooking. The cooking indicator light will illuminate and the display begins a chasing pattern.
9. The cooker will count down the final 12 minutes of cook time.
10. Once grain is finished, the cooker will beep and automatically switch to **Keep Warm**.
11. Let the barley sit on **Keep Warm** function for 10 minutes before serving.
12. When finished serving, turn the cooker off by pressing the (⏻) button and unplug the power cord.

COOKING BULGUR

UNCOOKED GRAIN	LIQUID	MIN GRAIN	MAX GRAIN	COOKING TIME	FUNCTION
1 Part	2 Parts	2 Cups	7 Cups	35-50 Min.	Brown Rice

1. Add desired amount of rinsed bulgur and a small amount of oil to the inner pot.
2. Fill the inner pot with the appropriate amount of liquid based on the ratio chart above.
3. Place the inner pot into the cooker.
4. Close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press the (⏻) button to turn on the cooker.
7. Press **Brown Rice**.
8. The cooker will now begin cooking. The cooking indicator light will illuminate and the display begins a chasing pattern.
9. The cooker will count down the final 12 minutes of cook time.
10. Once grain is finished, the cooker will beep and automatically switch to **Keep Warm**.
11. Let the bulgur sit on **Keep Warm** function for 10 minutes before serving.
12. When finished serving, turn the cooker off by pressing the (⏻) button and unplug the power cord.

ARC-150SB

COOKING COUSCOUS

UNCOOKED GRAIN	LIQUID	MIN GRAIN	MAX GRAIN	COOKING TIME	FUNCTION
1 Part	1 Part	2 Cups	10 Cups	29-60 Min.	White Rice

1. Add desired amount of rinsed couscous and a small amount of oil to the inner pot.
2. Fill the inner pot with the appropriate amount of liquid based on the ratio chart above.
3. Place the inner pot into the cooker.
4. Close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press the (⏻) button to turn on the cooker.
7. Press **White Rice**.
8. The cooker will now begin cooking. The cooking indicator light will illuminate and the display begins a chasing pattern.
9. The cooker will count down the final 10 minutes of cook time.
10. Once grain is finished, the cooker will beep and automatically switch to **Keep Warm**.
11. When finished serving grains, turn the cooker off by pressing the (⏻) button and unplug the power cord.

COOKING OATMEAL

UNCOOKED GRAIN	LIQUID	MIN GRAIN	MAX GRAIN	COOKING TIME	FUNCTION
1 Part	2 ½ Parts	1 Cup	2 Cup	35-42 Min.	White Rice

1. Add desired amount of rinsed oats and a small amount of oil to the inner pot.
2. Fill the inner pot with the appropriate amount of liquid based on the ratio chart above.
3. Place the inner pot into the cooker.
4. Close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press the (⏻) button to turn on the cooker.
7. Press **White Rice**.
8. The cooker will now begin cooking. The cooking indicator light will illuminate and the display begins a chasing pattern.
9. The cooker will count down the final 10 minutes of cook time.
10. Once grain is finished, the cooker will beep and automatically switch to **Keep Warm**.
11. Stir oatmeal thoroughly before serving.
12. When finished serving, turn the cooker off by pressing the (⏻) button and unplug the power cord.

NOTE: Min & Max Cup Amount refers to the plastic measuring cup provided with your rice cooker. If you misplace the measuring cup, a ¾ standard US cup is an exact replacement.

COOKING QUINOA

UNCOOKED GRAIN	LIQUID	MIN GRAIN	MAX GRAIN	COOKING TIME	FUNCTION
1 Part	1 ½ Parts	2 Cups	10 Cups	32-48 Min.	White Rice

1. Add desired amount of rinsed quinoa and a small amount of oil to the inner pot.
2. Fill the inner pot with the appropriate amount of liquid based on the ratio chart above.
3. Place the inner pot into the cooker.
4. Close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press the (⏻) button to turn on the cooker.
7. Press **White Rice**.
8. The cooker will now begin cooking. The cooking indicator light will illuminate and the display begins a chasing pattern.
9. The cooker will count down the final 10 minutes of cook time.
10. Once grain is finished, the cooker will beep and automatically switch to **Keep Warm**.
11. When finished serving, turn the cooker off by pressing the (⏻) button and unplug the power cord.

COOKING RISOTTO

UNCOOKED GRAIN	LIQUID	MIN GRAIN	MAX GRAIN	COOKING TIME	FUNCTION
1 Part	2 Parts	2 Cups	5 Cups	12-17 Min.	Steam

1. Add desired amount of rinsed arborio rice and a small amount of oil to the inner pot.
2. Fill the inner pot with the appropriate amount of liquid based on the ratio chart above.
3. Place the inner pot into the cooker.
4. Close the lid securely.
5. Plug the power cord into an available 120V AC wall outlet.
6. Press the (⏻) button to turn on the cooker.
7. Press **Steam**. Set the time for 12 minutes.
8. The cooker will now begin cooking. The cooking indicator light will illuminate and the display begins counting down.
9. Once grain is finished, the cooker will beep and automatically switch to **Keep Warm**.
10. If more cooking time is needed, **Steam** an additional 5 minutes
11. Stir risotto thoroughly before serving.
12. When finished serving, turn the cooker off by pressing the (⏻) button and unplug the power cord.