

Purchased your product online?

We would really appreciate it if you can share your experience with others by reviewing our product on the website from which you purchased.

Owner's Manual
Item # QLP542SLR-GR



Solar Bluetooth-Enabled Rock Speaker - Gray



Have Questions or Issues? Need help with assembly?
Contact us and we will resolve them within 12 hours.

Support Hours: M-F 7:30-5:00 (U.S. Pacific Time)



Call:
877-460-4511



Email:
info@alpine4u.com



Limited Warranty Information

Thank you for choosing an Alpine product! We aim to please with our wide range of products including Fountains, Birdbaths, Statuary, Pond Supplies & More. All of our products are constructed from the highest quality materials. In the event that we have not achieved our usual standard of excellence, we will repair or replace, at our discretion, within the warranty period. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise will also be required to help distinguish the actual cause of the defect. Please read below for a detailed description of warranty coverage.

- **Water Damage**

Alpine products are not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within a product may cause damage, is considered negligence, and will not be covered under this warranty. The use of "hard water," and/or caustic cleaners, can affect the painted or other finishes. Failure to keep the unit clean, and use of such additives/cleaners, will also void the warranty. Please note: for fountains, it is normal for some splashing to occur and protecting the immediate surfaces is not the responsibility of Alpine Corporation.

- **Paint & Color (Retention and/or Loss)**

The use of water will cause natural erosion to the color. This area can be touched up using standard paint. The paint is designed to protect the entire finish against breakdown of color. As with any product, all finishes with time will gradually fade and discolor. The warranty will only

cover against severe or complete fading, within the first year from date of purchase, with the above exclusion.

- **Procedure/Service**

Should a warranty/claim be needed, you should contact the retailer from whom you purchased the product. If that is not an option, you can contact Alpine Corporation at www.alpine4u.com. When contacting Alpine Corporation, you must be prepared to show proof of purchase, provide photographs and any other information needed to validate your claim. This may be necessary to distinguish between a partial or complete replacement of a defective product. The warranty does not cover any items with multiple parts; the warranty will ONLY cover the individual component of the unit/item that may be defective. Replacement parts can be made available to a consumer through the original selling party, or an approved parts retailer. If this is not an option, contact our customer service department. **Item is covered under one year limited warranty from the date of purchase. When requesting replacement parts due to a warranty claim after 30 days of purchase, credit card information will be requested for shipping charges.**

- **Not Covered Under Warranty**

The limited warranty will NOT cover cases of damages due to:

1. Damages caused in Transit
2. Inadequate care and/or neglect
3. Environmental and/or natural elements

4. Immersion in water, unless specified
5. Improper Installation/Storage and/or Maintenance

This warranty is void if the product has been damaged by accident, misuse, negligence, improper installation and/or modifications have occurred. This includes any and/or all defects arising out of freezing water damage, hard water damage, failure to keep the unit clean and free of harmful additives such as bleach, chlorine, etc.... which affects the paint and/or parts. This warranty also does not cover any additional charges or installation, removal, disposal and/or shipping costs or consequential damage associated with any warranty claim.

8

CONTENTS

Contents	1
What's Included.....	2
Features.....	3
Charging the Speaker with a USB cable.....	4

WHAT'S INCLUDED

Charging the speaker with the solar panel... 5	
Basic operation..... 5	
Pairing the speaker with a Bluetooth device. 6	
Playing Music..... 7	

Replacement Parts.....7	
Warranty..... 8	

5. When the Bluetooth device finds the speaker, select “Alpine Corporation” from the list of discovered Bluetooth devices.
6. After a successful pairing, a tone will be heard and the Bluetooth indicator light will light up GREEN.



Notice: *If you would like to pair the speaker to another device, you must unpair the speaker from the currently paired device first. On your device’s Bluetooth settings, select “Alpine Corporation”, then select unpair. When the speaker has been unpaired, it automatically goes into pairing mode again.*

**** Note:** *Multiple Rock Speakers cannot be paired to the same device at the same time. Use Speaker per device.*

one Rock

Solar Bluetooth Speaker -1



36" USB Charging Cable -1

To enjoy wireless music on your Bluetooth speaker, make sure that you are connected to a Bluetooth enabled device. Open your media player and press PLAY. Once playback begins, you can control the music and volume from your connected device.

Playback time on built-in battery is approximately 12 hours, depending on music level and other factors.


- Li-Ion Rechargeable Battery

REPLACEMENT PART	ITEM#
• USB Charging Cable.....	QLP596-2 RRR168

CHARGING THE SPEAKER WITH A USB CABLE

1. Plug the small end of the Micro USB Charging Cable into the Micro USB port on the back of the speaker.
2. Connect the larger end of the Micro USB Charging Cable into your computer or other USB charging device. Recommended charge time with a USB cable is 2-3 hours.

3. When charging is complete, remove the Micro USB Charging Cable from the speaker.



** When the Speaker is charging the LED light will turn RED, when the Speaker is fully charged the LED light will turn GREEN.

4

CHARGING THE SPEAKER WITH THE SOLAR PANEL

Solar and Bluetooth Speaker comes with a built-in rechargeable battery. Prior to using the speaker for the first time, it is recommended to charge the battery fully for the first time.

Place the speaker under direct sunlight or in a brightly lit room so the speaker can begin charging.

Recommended charge time using the Solar Panel is 8 hours. It is important you charge the speaker for at least 8 hours before using it for the first time.

**Charge times may vary depending on solar conditions.*



Solar Charging Panel

Powering On/Off

Push the power button on the back of the speaker to turn the speaker ON or OFF.



5


PAIRING THE SPEAKER WITH A BLUETOOTH DEVICE

1. Turn the speaker ON.
2. A tone will be heard and the Bluetooth indicator light will quickly flash BLUE / GREEN.
3. Keep the speaker and Bluetooth-enabled device within three feet of each other during the pairing process. Set your Bluetooth-enabled device to search for the Bluetooth devices.
4. If there are no paired devices in range when the speaker is turned on, it will go into pairing mode automatically. If a paired device is in range, the speaker will connect to it automatically.

-Pairing an iOS Phone/Device: • Go to Settings > BLUETOOTH (Make sure Bluetooth is ON)

FEATURES

- **Weather Resistant Outdoor Design**
- **4" Full Range High Intensity Speaker**
- **Bluetooth 4.0 Works up to 50 ft.**



-Pairing an Android Phone/Device:

- Go to Settings > Connections > Bluetooth
- Search for devices. (Make Sure Bluetooth is ON)

-Pairing other Cell Phones/Devices:

- Review the instruction manual that came with your phone/device.

- Solar powered, even on cloudy days
- Micro USB charging port for fast charging
- Lithium Ion Rechargeable Battery for up to 10hrs use

