

**Smart Plug Instruction** WP3



**2.4G** Wi-Fi  
Ready



**5G** Wi-Fi  
Not supported

Since the device only supports 2.4G Wi-Fi connection, please ensure that the mobile phone and the device are connected to 2.4G Wi-Fi simultaneously.

## What's in the Box

Smart Plug

User Manual


x1

Binding Voice Assistants Guide

x1

## At a Glance

- ① ON/OFF Button
- ② Indicator Light
- ③ Flame Resistant Material



## Parameters

Model: WP3

Input: 120V, 50/60Hz, 10A MAX

Output: 1200W MAX resistive

Frequency Range: 2400-2483.5 MHz

Wi-Fi Network: 802.11 b/g/n, Only 2.4GHz

WiFi MAX Transmitting Power(dBm): <20dBm

Main Dimensions:

φ2.03 in (Diameter) x 1.20 in (Thickness);

Total length including Contact / Terminal : 1.97 in

## Main Features



Voice Control



App Control



Schedule Timer



Family Sharing



Group Control



No Hub  
Required



Mini Size



V0 Fireproof  
Materials

## How to Download the GHome App

**Option 1:** Search for "GHome" in the Apple App Store or Google Play.

**Option 2:** Scan the QR code to enter the download page.



**Note:** Your phone must run iOS 11+ or Android 6.0+ for a smooth connection.

## **How to Pair with the GHome App**


1. Open the "GHome" App and create your GHome account.
2. Turn on the plug and place it near the router when pairing.
3. Hold the ON/OFF button for 5 seconds and release when the indicator light starts to blink slowly to enter the network pairing mode.



Connect your phone to the Wi-Fi router, click the "+" at the top right corner of the homepage to add a device.

You can add a device in two ways.

1) **Automatic Pairing (Recommended)**

1. The device will be automatically discovered by the app.
2. Tap the device, enter your **2.4G Wi-Fi** name and password, tap "Next".
3. Once the device is added successfully, tap "Done".








## 2) **Manual Pairing (AP Mode)**

If Bluetooth networking fails to discover the device:

1. Go to "**Add Manually**", select "**WP3**" under "**Sockets**".
2. Confirm the indicator is blinking slowly, then tap "**Confirm light flashes**".
3. Select **2.4 GHz Wi-Fi** Network and enter password, then tap "**Blink Slowly**".
4. Connect your phone to the device hotspot "SmartLife-XXXX".
5. Return to the GHome App interface, it will automatically connect to the router, completing the configuration.







## **Reset**

Turn on the power, hold the ON/OFF button for 5 seconds, and let it go, when the indicator light starts blinking slowly, the reset process is successful. When the socket is in a new network environment, you need to restore the factory settings, and then reconnect to the network.

**If the Smart Plug WP3 fails to connect to a 2.4G frequency band network, try the following solutions:**

**1. Check if the router's 2.4G band is enabled:**

Access the router's management interface to verify that the 2.4G WiFi is activated (some routers disable it by default or only enable 5G).

Ensure the 2.4G signal is transmitting properly.

**2. Verify network information:** Confirm the socket is connecting to the 2.4G WiFi (its name often includes "2.4G"). When entering the password, check for errors caused by special characters (e.g., mistyping "0" as a similar-looking symbol).

**3. Reduce interference and adjust distance:** Place the smart socket closer to the router (avoid walls or metal obstacles) and keep it away from interference sources like microwaves or Bluetooth devices. In the router settings, change the 2.4G channel to less crowded ones like 1, 6, or 11.


**4. Check device restrictions:** Log into the router's management interface to see if the smart socket is on the blacklist; remove it if so. Ensure settings like "only 5G devices allowed" are disabled.

**5. Restart and retry:** Reboot both the router and the smart socket, then redo the network configuration steps. If it still fails, the device may be faulty—contact the manufacturer's after-sales service for inspection.

## **Plug the device into the socket.**

### **Notice:**

- a. Make sure the distance between the device and the router is less than 100ft. (In case of obstructions, the recommended distance should be less than 50ft.)
- b. Keep as few obstructions (e.g. wall, windows) as possible between the device and the router.



## Warnings and Precautions

### Important!

- Keep it out of the reach of children and pets.  
Do not use this product in humid environments or outdoors. It's for indoor use only.
- Do not place this product near heating devices, such as microwave ovens, stoves, or radiators.
- Protect the product from extreme temperatures, direct sunlight, strong jolts, high humidity, moisture, flammable gases, vapors and solvents.
- Do not disassemble, modify, or repair your device, and ask help from the authorized professionals for device malfunction.

- Do not use the device when it is no longer working properly or visibly damaged.
- Do not insert your device to another one.
- Never use aggressive detergents such as alcohol or other chemical solutions because these could damage the casing or even impair the functioning of the product.

Note: The image shown in the manual is indicative only. If there is inconsistent between the image and the actual product, the actual product shall govern.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Warning Statements:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.



Made in China



Intertek  
5011128

