


# Quick Start Guide

---

## A886

Tattoo Printer



English

# 1. Product Introduction

## 1.1 Packing List



Printer  
×1



Quick Start Guide  
×1



Type-C Cable  
×1



Velvet Pouch  
×1




USB to Type-C Adapter  
×1



Tattoo Transfer Paper -  
10 Sheets ×1

## 1.2 Printer Parts Instruction



## 2. Getting Started

### 2.1 Downloading the App

**Method 1:** Search for the "Phomemo" app on App Store® or Google Play™ for download and installation.



Phomemo


**Method 2:** Scan the QR code to download the app.

You can scan the code using your cell phone's camera, the built-in QR code scanning feature of your browser, or a dedicated QR code scanning app.



ⓘ As the Safari browser on Apple devices does not support direct QR code scanning, please use your device's built-in QR code scanner instead.


## 2.2 Tattoo Transfer Paper Introduction



⚠ This area is the adhesive seam at the top of the paper; please do not tear it!


## 2.3 Preparation Before Use

- 01 Take out a piece of tattoo transfer paper, and remove its Protective Sheet.




- 02 Trim the Yellow Backing Sheet along the top adhesive seam with a ruler or scissors.

Method 1



Yellow Backing Sheet

Method 2




Yellow Backing Sheet


⚠ When cutting, please make sure that the adhesive area remains intact.

## 2.4 Paper Installation Guide


- 01** Long press the Power Button for 3 seconds until the Indicator Light is green to power up the printer.




- 02** Simultaneously press the Cover Open Buttons with both hands.



- 03** Open the Top Cover.




- 04** Remove the protective paper.




① Please skip this step if your printer does not contain a disposable protective sheet due to different models.

- 05** Place the white tracing paper face up and flat into the printer in the direction of the paper outlet. Make sure the tattoo paper covers the sensor.



- 06** Put the Top Cover back down, and press down on both of its ends at the same time until you hear a click, indicating the cover is securely closed.




## 2.5 User Guide: Printing via Mobile App

**01** Open the "Phomemo" app.




**02** Grant permissions.




**03** Wait for the printer to be searched.



**04** Tap [Connect Now].



- 05** The printer is connected.  
Tap [Paper loaded, starting printing].



- 06** Edit your first image, and tap [ ] after you finish editing.




- 07** Confirm the preview of the image, and tap [Print].




- 08** Printing is completed.



- 09** Retrieve the printout.




- 10** Tear off the White Tracing Sheet for use.



⚠ The software interface is for reference only. Please refer to the actual operating page for accurate information.


## 2.6 User Guide: Printing via computer

- 01** Connect the printer to the computer using the original Type-C cable supplied with the printer.



- ①** • If your computer is Type-C interface, you can use the supplied adapter to convert the interface, the Type-C end of the adapter needs to be plugged into the computer side.  
• The adapter is unidirectional, and the Type-C end of the adapter plugged into the printer end will fail to charge or fail to transfer data abnormally.

- 02** Visit [a886.labelife.cc](http://a886.labelife.cc) to download and install the driver.





- 03** Select and open the file you need to print.



- ①** The file formats supported by the printer include JPG, PNG, etc.



04 Tap .



05 Select the A886 Printer, and click  to start printing.




06 Retrieve the printout. Tear off the White Tracing Sheet for use.









## 3. Additional Instructions

### 3.1 Button Instructions

| Button Type   | Operation                       | Function               |
|---|---------------------------------|------------------------|
| <br>Power Button | Long press for 3s               | Power on/off           |
|   | Double press when printer is on | Print a self-test page |


### 3.2 Indicator Light Instructions

| Status  | Meaning                       | Advised Action  |
|---|-------------------------------|---|
|  Solid Green Light                                 | Functioning/Fully charged     | /   |
|  Flashing Green Light                             | Charging while printer is on  | /   |
|  Solid Red Light                                   | No paper installed            | Install paper   |
|   | Printer overheated            | Pause printing for 5-10 min                               |
|   | Top Cover open                | Close Top Cover   |
|  Flashing Red Light                               | Low battery                   | Charge battery for 1h(or at least 20 min for quick usage) |
|  No light after long pressing Power Button for 3s | Battery depleted              | Charge for 4h   |
|  Alternately Flashing Red and Green Light         | Charging while printer is off | /   |


## 3.3 Permission Description

For iOS users

- 01 The app requires access to the Internet




- 02 The app requires Bluetooth permission



For Android users

- 01 The app requires Bluetooth permission




- 02 The app requires permission to search for nearby Bluetooth devices



ⓘ For Android 12 and above, the app requires permission to search for nearby Bluetooth devices; for systems below Android 12, the app requires GPS permission in order to search for nearby Bluetooth devices.

- 03 Bluetooth Pairing Request



ⓘ You can simply tap "Pair" without checking "Allow access to your contacts and call history."

## 4. More Connection Methods

### 4.1 Connecting via Bluetooth

01 Open the "Phomemo" app.



02 Click on the top [Connect].



03 Go to Bluetooth Connections and search for the printer.




04 Select your printer



ⓘ Turn on Bluetooth permission to quickly find and connect to the printer.

05 Device connected




## 5. Cleaning and Maintenance

**①** Disconnect the printer from the power supply before starting any cleaning or maintenance.

If you encounter issues such as blank lines, blurry print, or missing words, it may be caused by dirt on the Print Head. Please follow these steps:


- 01** If you have just finished printing, wait for at least 30 minutes for the Print Head to cool down completely.
- 02** Use a cotton swab dipped in alcohol or a dry alcohol-soaked cotton ball to gently wipe the Rubber Roller and the Print Head left and right 5 times each, removing dust and stains from the surfaces.
- 03** Wait 5-10 minutes for the alcohol to evaporate completely before closing the Top Cover and completing the cleaning process. You may now continue using the printer.



## 6. Charging Instructions

1. Please prepare your own power adapter (DC 5V $\Rightarrow$ 2A) with a Type-A port.
2. Insert the Type-C end (flat end) of the USB cable into A886's Type-C Charger Port and plug the Type-A end (wide end) into the Type-A port of the power adapter.
3. After connecting the printer to an outlet using the power adapter, please check the status of the Indicator Light: a light flashing alternately between red and green indicates that the printer is off, while a flashing green light signals that the printer is on.
4. To ensure quick usage, please charge the printer for at least 20 minutes. For a complete charge, wait for 4 hours or until the Indicator Light is solid green.
5. As the printer may heat up during charging, avoid placing it on materials such as cotton or linen.
6. Once the battery is fully charged, please unplug the charger promptly.

ⓘ Avoid using the printer while charging. Using the printer while charging may lead to reduced charging speed, compromised print quality, and shortened battery life.



## 7. Information to User

### 7.1 FCC WARNING

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

### 7.2 ISED NOTICE (Canada)

- English:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

IC RF exposure statement:

The device has been evaluated to meet general IC RF exposure requirement. The device can be used in portable exposure condition without restriction.

- French:

L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes :

- 1) L' appareil ne doit pas produire de brouillage;
- 2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement

IC Déclaration d'exposition aux RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF d'IC. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

---

## Special Notes

---

The company assumes full responsibility for the revision and explanation of this manual, exercising utmost diligence to guarantee its accuracy. Nevertheless, please note that any technical improvements to the product may not be separately notified, and that the images of the product, accessories, software interfaces, etc. in this manual serve solely as illustrations and references. Due to product updates and upgrades, the actual product may vary slightly from the images. Please refer to the physical product for accurate representations.