



TRAMSMART



Smart Recessed Downlight

Multicolor & Tunable White

Model: SDL0505-13

Welcome

Thank you for purchasing Tramsmart home products!

We are committed to bringing you excellence. Tramsmart home technology products are convenient, make your life more comfortable and provide a more dynamic lifestyle.

General Notice

Always make sure to follow safety instructions.

- Do not use products if they have become damaged.
- Follow instructions and only operate products in a safe environment.
- Do not operate electronics in wet conditions. Doing so may cause property damage, bodily harm or electrocution.
- Do not disassemble or alter the product. Doing so will void the warranty.

Table of Contents

Welcome	01
Tramsmart App	03
Configure Settings	13
Google Home	15
Alexa	18

What's Included



Smart Recessed Downlight




I/M



E26 Adapter

Structure Introduction




Download and Install the Tramsmart APP

Search and download “Tramsmart” in major application markets or scan the QR code below to download the App.



Sign In App



Step 1: Sign in with mobile phone number + verification code. Select your country code, enter the phone number and tap “Get Verification Code” to get a message and tap “Log in” to login the App.

Step 2: Sign in with social media account.

Device Pairing-Easy In



- Turn on the Smart Recessed Downlight and enter the home page of Tramsmart App while ensure Bluetooth on and the Wi-Fi signal is good and stable.
- Smart Recessed Downlight will be blinking fast when turn on the power supply. Stay at the home page and found the push notification, then click “Go to add”.
- Note: If the light is not blinking fast, please turn off the lamp, and then switch it following the steps: On-off-on-off-on until it's blinking fast. Switch time interval shall not exceed 10 seconds. Attention: Please complete pairing process within 3 minutes after device reset.
- After the first connection, you can use a new Wi-Fi or mobile data traffic to control lights anytime and anywhere.

Select Device to Add



- You will be able to manually add a device.
- Select “Smart Recessed Downlight RGB+CCT Wi-Fi+Bluetooth”.

Enter Wi-Fi Password



- Select the Wi-Fi connected to the Smart Recessed Downlight, input the Wi-Fi password, and then tap “Confirm”.
- Please confirm that the phone and Smart device are in the same Wi-Fi environment.
- Note: The product only support 2.4GHz Wi-Fi network. It doesn't support 5GHz Wi-Fi network.

Connecting




- The interface of connecting will appear, when the device is found, the lamp will stop blinking and then initializing device will be complete.

Confirmation Screen




- The smart device is added once they are communicating on the same Wi-Fi Network.
- You can rename the smart device by clicking on the pencil icon.
- You can specify the location. Press the “Done” button at the bottom of screen to continue to next step.

Home Screen Updated



- Now that your device has been added, it will show on the home screen along with all other paired Tramsmart Products. Now you are all set.
- The device name of your Smart Recessed Downlight shows in the “All Device” list, tap it to enter the control panel of the Smart Recessed Downlight.


Features: White Mode



The White Mode screen will allow basic controls over the standard lighting mode.

- Bright controls the brightness.
- Color Temp allows the light to take different moods.


Color Mode



Color Mode allows additional controls over the lighting.

- Saturation will give more brilliance to the lighting.
- Bright will allow control over light intensity.


Scene Mode



Scene Mode allows additional controls for preset lighting.


- Each light mode will provide different lighting effects to choose from.

Music Mode



- You can minimize the Tramsmart App to play music from any source. Your Smart Recessed Downlight will automatically synchronize and change color to the music.


Random Timing



In this mode, the Smart Recessed Downlight will turn itself On/Off at a random time point which varies from 30mins before pre-set Start/End Time to 30mins after pre-set Start/End Time.

1. Click "More".
2. Click "Plan".
3. You can select timing type "Random timing".
4. You can choose the Start/End Time.

Cycle Timing



Under this mode, the Smart Recessed Downlight will turn itself On/Off at several time nodes set by you with an adjustable cycling program.

1. Click "More".
2. Click "Plan".
3. You can select timing type "Cycle timing".
4. You can choose the Start/End Time.

Sleep Plan




1. Click "More".
2. Click "Plan".
3. You can select plan type "Sleep plan".
4. First configure the hours (left).
5. Next configure minutes (right).
6. You can customize the repetition time.
7. Click "Save" to save the settings.

Wake Up Plan



1. Click "More".
2. Click "Plan".
3. You can select plan type "Wake up plan".
4. First configure the hours (left).
5. Next configure minutes (right).
6. You can customize the repetition time.
7. Click "Save" to save the settings.


Schedule



This will keep the lamp in ON/OFF position for a specific duration of time.

1. Click on "Schedule".
2. Click "Add".
3. First configure the hours (left).
4. Next configure minutes (right).
5. Click "Repeat" and choose the day of the week.
6. Select the state of the switch (ON/OFF).
7. Click "Save" to save the settings.



Timer



This will keep the lamp in ON/OFF position for a specific duration of time.

1. Click "Time".
2. Select the switch that needs to be set.
3. First configure the hours (left).
4. Next configure minutes (right).
5. Click "OK" to save the settings.

Biorhythm



- Change the color temperature of the lights adjusts naturally to keep your body in its natural rhythm.
- Light has a big effect on our circadian rhythm and our regular lighting interferes with your circadian rhythm causing health problems.
- Our Smart Recessed Downlight can be programmed to give you the correct amount of light at the correct color temperature to work in harmony with our circadian rhythm instead of against it.


Configure the Light Lamp Settings

Different features can be adjusted from the menu button on the upper right hand button “ ∠ ” on the APP.

1. Device Name can be changed as desired.
2. Device information can check the information of the Smart Recessed Downlight.
3. Tap-to-Run and Automation allows to check the Smart Automation your device linked with.
4. Supported Third-Party Control provides the information about how to connect your device to Amazon Alexa, Google Assistant.
5. Offline Notification allows to alert you when your device is offline.
6. Add Members to be able to control the device in the Share Device setting.
7. Create Group to control other smart device at the same time.
8. FAQ & Feedback allows users to report issues and get help.
9. Add to Home Screen allows you to add the Smart Device to the home screen of your smartphone.
10. Check Device Network allows you to check the network connection status.
11. Firmware Information allows to check software or install updates to device.
12. Remove device will remove the Smart Device from the Trasmart App and remove pairing. This is necessary if pairing with a new device.
13. Restore Factory Defaults allows to reset the Smart Device to factory setting.



Installation

1. Make sure the power is turned off at the source to the recessed can.
2. Screw the E26 socket adapter into recessed can socket by turning clockwise. (This retrofit downlight was set for 5-6 inch fixture housing.)
3. Plug E26 adapter's male connector to the downlight's female connector.
4. Push two ends of the Flip Clip toward each other till it can fit into the recessed can.
5. Install the downlight up into recessed can firmly until the rim ring is flush with the ceiling.
6. Turn on the power supply and connect with our App to control the light.







Link Tramsmart account to Google Home Screen

1. Open Google Play store or Apple Store and download Google Home.
2. Open the Google Home app. Click on Get Started.
3. Login with a Google Account or create a new account.
4. Use location access to find devices on the same Wi-Fi network.





5. You will need to permission so Google Home can access device.
6. The app will search for devices to connect.
7. If no devices can be found that they are already setup, select NO.
8. A YouTube video is available to help instruct how to use Smart devices.



9. The App will show settings to add devices, setup routines, and adjust settings.

10. If the devices are already installed and setup through the Trasmart App, you can select the “works with Google” setup option to continue.

11. Configure the home settings by adding address and name to a “Home” group.





Control your Smart devices through Google Home

Now you can control your Smart devices through Google Home. Take bedroom light as the example, the supported voice commands are as below:

1. OK Google, turn on/off bedroom light.
2. OK Google, set bedroom light to 50 percent.
3. OK Google, brighten bedroom light.
4. OK Google, dim bedroom light.
5. OK Google, set bedroom light to red.

Link Trasmart account to Alexa

1. Download the free Alexa app from the Amazon Appstore, Google Play, or the Apple App Store.
2. Open Alexa app to home screen.
3. In upper left hand corner open the menu.
4. Next click on "Skills & Games".
5. In top of app you can now search for "Trasmart".
6. Trasmart App will appear.







7. Open the Trasmart app to add.

8. Click Settings.

9. Manage Smart Home Devices to verify Trasmart has been added.

10. You will be redirected to the account link page. Type in your Trasmart account and password, don't forget to select the country/region where your account belongs to. Then tap "Link Now" to link your Trasmart account. The country/region, the account, and the password must match.



The products are not designed for use in

- For safety reasons, do not open device, doing this will void the warranty.
 - Only use the adaptor supplied; using a different adaptor can damage the device.
 - Only use this lamp in a socket that is rated for this lamp.
 - This device is not designed to be played with by children like a toy.
 - Do not place the device on hot surfaces.
 - Before replacing, turn off power and let the lamp cool to avoid electrical shock or burn.
 - Risk of electric shock.
 - Do not use device where directly exposed to water.
 - The device is for indoor use only.
 - Do not use the device in wet locations, e.g. bathrooms or outdoors.
-

While using this product

- Switch off the power supply to the socket and allow sufficient time for the lamp to cool before removing the lamp from the fitting.
 - Do not clean the device when it is on and connected to the power supply.
 - Do not open device, as this will void the warranty.
 - To avoid scratching the device, clean only with a soft dry cloth.
 - Do not use cleaning agents to clean the device.
-

CAUTION

- **DO NOT USE FOR DAMP LOCATION**
- **DO NOT USE WITH DIMMERS**
- **NOT FOR USE IN TOTALLY ENCLOSED LUMINAIRES**
- **THIS LAMP IS NOT INTENDED FOR USE WITH EMERGENCY EXITS**

Wireless Specification

- Wi-Fi Standard: IEEE 802.11b/g/n
 - Bluetooth Standard: IEEE 802.15.1
-

Model Details

Model	Rating	Luminous Flux	Base	Power (W)
Smart Recessed Downlight RGB+CCT	AC110-130V 60Hz	1100lm	E26	13

Customer Service and Tech Support

Your satisfaction is important to us. We are here to help!

Contact us at info@tramsmart.co

Include your order number and product description.

See our website for more products www.tramsmart.co

We enjoy your feedback!

To find the latest revision of this publication, visit our website at www.tramsmart.co



TRAMSMART