

COOSII



Sound Optimized for You

H300 Wireless Headphones

Contents

1. What' s in the Box
2. Schematic
3. Wearing
4. Bluetooth Connection
5. Dongle Connection
6. LED Indicators
7. Button Control
8. Turn on/off Microphone
9. Charging the Battery
10. Troubleshooting
11. Specification
12. Warning

What's in the Box




Headphone * 1



Audio cable * 1



Charging cable * 1




User manual * 1



USB Dongle * 1

Schematic




1. Multi-function Button

Power On/ Off Button
Music/ Call Control Button
Previous/ Next Track Button

2. M Button

Switch Between Dongle / Bluetooth Mode
Microphone Mute/ On

- 3. Volume Up/ Down
- 4. Microphone Pole
- 5. Microphone LED Indicator
- 6. 3.5mm Audio Jack
- 7. Bluetooth LED Indicator
- 8. USB Charging Slot




- 1. LED Indicator
- 2. Multi-function Button
- 3. USB Port

Wearing



Pairing and Connecting with a Smartphone

The operation to register the device that you wish to connect to is called “pairing”. First, pair a device to use it with the headphone for the first time.



Before starting the operation, make sure of the following:

- The smartphone is placed within 1m (3 feet) of the headphone.
- The headphone is charged sufficiently.

1. Press and hold the  button on the headphone for about 3 seconds until the red and blue light flash alternately, you will hear the voice guidance say, “power on”.
2. Make sure the headphone is in Bluetooth mode.
Note: Switch the “Bluetooth mode” and the “Dongle mode” by long press the  button for 3 seconds, you will hear the voice guidance say “Bluetooth mode” or “Dongle mode”.
3. Open the Bluetooth function on your smartphone and click H300 on the list.

The headphone and smartphone are paired and connected with each other. You will hear the voice guidance say, “connected”.

Pairing and Connecting with a Computer/ Laptop which Built-in Bluetooth Function (Windows)

The operation to register the device that you wish to connect to is called “pairing”. First, pair a device to use it with the headphone for the first time.



Before starting the operation, make sure of the following:

- Your computer has a Bluetooth function.
- The computer is placed within 1 m (3 feet) of the headphone.
- The headphone is charged sufficiently.
- The operating instructions of the computer is in hand.
- Depending on the computer you are using, the built-in Bluetooth adaptor may need to be turned on. If you do not know how to turn on the Bluetooth adaptor or are unsure if your computer has a built-in Bluetooth adaptor, refer to the operating instructions supplied with the computer.

1. Press and hold the  button on the headphone for about 3 seconds until the red and blue light flash alternately, you will hear the voice guidance say, “power on”.
2. Make sure the headphone is in Bluetooth mode.
Note: Switch the “Bluetooth mode” and the “Dongle mode” by long press the  button for 3 seconds, you will hear the voice guidance say “Bluetooth mode” or “Dongle mode”.
3. Open the Bluetooth function on your computer and find H300 on the list.

The headphone and computer are paired and connected with each other. You will hear the voice guidance say, “connected”.

Pairing and Connecting with a Computer (Mac)

Compatible OS
macOS (version 10.10 or later)




Before starting the operation, make sure of the following:

- Your computer has a Bluetooth function.
- The computer is placed within 1 m (3 feet) of the headphone.
- The headphone is charged sufficiently.
- Depending on the computer you are using, the built-in Bluetooth adaptor may need to be turned on. If you do not know how to turn on the Bluetooth adaptor or are unsure if your computer has a built-in Bluetooth adaptor, refer to the operating instructions supplied with the computer.
- Set the computer speaker to the ON mode.
- If the computer speaker is set to the “OFF” mode, no sound is heard from the headphone.


Computer speaker in the ON mode



1. Press and hold the  button on the headphone for about 3 seconds until the red and blue light flash alternately, you will hear the voice guidance say, “power on”.
2. Make sure the headphone is in Bluetooth mode.
Note: Switch the “Bluetooth mode” and the “Dongle mode” by long press the  button for 3 seconds, you will hear the voice guidance say “Bluetooth mode” or “Dongle mode”.
3. Register the headphone using the computer.
--Select [System Preferences] - [Bluetooth] from the task bar in the lower right part of the screen.




--Select [H300] from the Bluetooth screen and click [Connect].



If Passkey (*) input is required, input "0000".

The headphone and computer are paired and connected with each other. You will hear the voice guidance say, "connected".



-- Click the speaker icon in the upper right part of the screen and select [H300].



--To set your paired COOSII H300 headphone as the default audio device for the computer:

If you'd like the headphone to be the default audio device, open System Preferences.

- Click the Sounds icon.
- Click Output, and then select H300 headphone.
- Click Input, and select H300 headphone.



Pairing and Connecting with a Computer Via Dongle Mode (Windows)



Before starting the operation, make sure of the following:

- The computer is placed within 1 m (3 feet) of the headphone.
- The headphone is charged sufficiently.
- The computer has a USB slot

1. Plug the COOSII USB Dongle into your computer

2. Press and hold the  button on the headphone for about 3 seconds until the red and blue light flash alternately, you will hear the voice guidance say, “power on”.

3. Make sure the headphone is in Dongle mode.

Note: Switch the “Bluetooth mode” and the “Dongle mode” by long press the  button for 3 seconds, you will hear the voice guidance say “Bluetooth mode” or “Dongle mode”.

4. The headphone and the Dongle will be automatically be connected with each other within 3-10 seconds, you will hear the voice guidance say, “connected”.

LED Indicator on Headphone

Indicator activity	System state
Red light blinking triple for every 5 seconds	Low battery
Blinking blue and red	In pairing mode
Blue light on for 1 second	Power on
Solid red	Charging

LED Indicator on USB Dongle

Indicator activity	System state
Solid blue	Connected
Blinking blue and red	In pairing mode

LED Indicator on Microphone Pole

Indicator activity	System state
Solid blue	Microphone on
No light	Microphone off

Button Control

* MFB= multi-function button


Indicator activity	System state
Power on	Press and hold th MFB for 3 seconds
Power off	Press and hold th MFB for 2 seconds
Volume +/-	Move the roller up and down
Answer a call	Press the MFB once
Reject a call	Double press the MFB
End a call	While on a call, press the MFB once
Next track	Double press the MFB
Previous track	Triple press the MFB
Turn on/off the microphone	Press the M button once
Switch Dongle mode / Bluetooth mode	Press and hold the M button for 3 seconds

Turn on/off Microphone

Short press **M** button for turn on/off the microphone, you will hear the voice guidance say, “microphone on” / “microphone mute”.

Charge the Headphones

1. Plug the small end of the USB cable into the micro-USB connector on the right earcup.
2. Plug the other end into a USB wall charger or computer that is powered on.



Note: While charging, the battery indicator red. When the battery is fully charged, and the indicator (red) turns off automatically.

Common solutions

If you could not resolve your issue, see the table below to identify symptoms and solutions to common problems. If you are unable to resolve your issue, contact COOSII customer service.

Symptom	Solution
Headphones don't power on	Charge the battery
Headphones don't connect with your mobile device	• Check the state of the status indicators. • On your mobile device: - Disable the Bluetooth feature and then re-enable. - Delete your H300 wireless headphones from the Bluetooth list on your device. Connect again. • Move your mobile device closer to the headphones and away from any interference or obstructions. • Connect another mobile device.
No sound	Power on the headphones and charge the battery. • Increase the volume on your headphones, your mobile device and music source.

	• Move your mobile device closer to the headphones and away from any interference or obstructions. • Use a different music source. • Connect another mobile device. • If two mobile devices are connected, pause your other device first. • If two mobile devices are connected, move the devices within range of the headphones (30 ft. or 10 m).
Poor sound quality	• Use a different music source. • Connect another mobile device. • Move your mobile device closer to the headphones and away from any interference or obstructions.
Battery won't charge	• Secure the ends of the USB charging cable. • Try another charging source. • If your headphones have been exposed to high or low temperatures, let the headphones return to room temperature and try charging again.

Specification

Model Name	H300
Impedance	$32\Omega \pm 15\%$
Frequency Response	20 - 2000Hz
Sensitivity	114dB $\pm$ 3dB
Bluetooth Version	V5.0
Drive Unit	40mm
Operation range	33 feet
Charging time	≥ 2 hours
Bluetooth protocol	A2DP/AVRCP/SMP/HFP

Please read and keep all safety and use instructions.

WARNINGS/CAUTIONS

- Do NOT use the headphones at a high volume for any extended period.
 - To avoid hearing damage, use your headphones at a comfortable, moderate volume level.
 - Turn the volume down on your device before placing the headphones in/on your ears, then turn the volume up gradually until you reach a comfortable listening level.
- Do NOT use your headphones while driving for phone calls or any other purpose.
- Do NOT use the headphones if they emit any loud unusual noise. If this happens, turn the headphones off and contact COOSII customer service.
- Remove headphones immediately if you experience a warming sensation or loss of audio.



Contains small parts which may be a choking hazard.
Not suitable for children under age 3.



This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.

- To reduce the risk of fire or electrical shock, do NOT expose this product to rain, liquids or moisture.
- Do NOT make unauthorized alterations to this product.
- Do NOT expose products containing batteries to excessive heat (e.g. from storage in direct sunlight, fire or the like).

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Made in China

FCC ID: 2APBQ-CSWL

Tested by UL62368-1 (UL Standard for Safety Audio/video, information and communication technology equipment – Part 1: Safety requirements)

Product Name: Wireless Headphones

Model No.: H300

Company: Shenzhen Kesi E-commerce Co.,Ltd

Address: 15/F Henglu E-time, No.159 Pingji Rd North, Hehua Community, Pinghu Longgang, Shenzhen,China

Email: service@coosii.com

COOSII

service@coosii.com