

**iLIVING**®

**v8**

**FOLDABLE  
MOBILITY  
SCOOTER**



**FULL USER MANUAL**



# TABLE OF CONTENTS

INTRODUCTION . . . . .	1
PRODUCT VIDEOS . . . . .	2
WHAT'S IN THE BOX . . . . .	2
OPTIONAL ACCESSORIES . . . . .	3
WARRANTY INFORMATION . . . . .	4
GENERAL SAFETY WARNINGS . . . . .	6
LABELS AND WARNINGS . . . . .	12
UNBOXING . . . . .	14
KNOW YOUR V8 SCOOTER . . . . .	15
UNFOLDING THE SCOOTER . . . . .	19
FOLDING YOUR SCOOTER . . . . .	20
BATTERY INSTALLATION . . . . .	21
CHARGING THE BATTERY . . . . .	23
OPERATING THE SCOOTER . . . . .	26
CARE AND MAINTENANCE . . . . .	30
ACCESSORY INSTALLATION . . . . .	32
BASIC TROUBLESHOOTING . . . . .	33
SCOOTER SPECIFICATIONS . . . . .	35
SUPPORT AND CONTACT INFORMATION . . . . .	36

# INTRODUCTION

Thank you for purchasing the iLiving V8 Foldable Electric Mobility Scooter. For over 10 years now, iLiving has been creating and distributing the finest products for your home, health, and well-being. Now, iLiving introduces its newest and most advanced product to date.

The V8 scooter is designed to be comfortable, mobile, and travel-friendly. The V8 scooter easily folds up in less than a minute, features a nimble, lightweight design, and ensures that this will be the best foldable mobility scooter you've ever bought.

At iLiving, we care about creating products that foster an active and healthy lifestyle. We believe that mobility scooters should complement an on-the-go lifestyle, rather than hinder it. As such, creating a scooter that is both easy to fold up quickly and carry became our goal.

It is imperative to the safe and effective operation of your V8 scooter that you read and understand this User Manual fully in its entirety. Before using the V8 scooter for the first time, familiarize yourself with the instructions and recommendations in this User Manual. If there is anything within this User Manual which you do not understand, or if you have any questions regarding the operation or maintenance of this scooter, please contact us right away at our Customer Service Department listed below.

Customer Service Department


1-800-317-1688  
M-F 9AM-5PM PST

[service@ilivingusa.com](mailto:service@ilivingusa.com)




## PRODUCT VIDEOS

Visit [foldablescooter.com](http://foldablescooter.com) or [iLivingUSA.com](http://iLivingUSA.com) to view detailed product videos on the iLiving V8 Foldable Mobility Scooter.



Official iLiving V8 Commercial



Official V8 Unboxing Video

---

## WHAT'S IN THE BOX

1. iLiving V8 Foldable Mobility Scooter
2. 2 V8 Scooter Keys
3. A/C Wall Charger
4. 2 Rechargeable Lithium Ion Batteries
5. Quick Start Guide
6. User Manual

# OPTIONAL ACCESSORIES

The following accessories listed below are available for purchase by contacting iLivingUSA directly, or on our website at [iLivingUSA.com](http://iLivingUSA.com).



**Armrests**



**Deluxe Seat  
(Available soon)**



**Carrying Bag/Basket  
(Available soon)**



**Rechargeable Lithium  
Ion Battery**

## WARRANTY INFORMATION

The V8 Scooter comes with a three (3) year limited parts and components warranty for the frame/structure of the scooter, and a one (1) year limited parts and components warranty for the electrical components of the scooter. The battery for the V8 Scooter is only covered under warranty for six (6) months. If a problem arises with your V8 Scooter, please contact us immediately.

If a problem arises with your V8 Scooter within 30 days of purchase, we will bring in the scooter for service at no cost to you. iLiving will pay for shipping of the scooter to and from our service center and waive all fees related to parts and labor. We require a proof of purchase; please keep your purchase receipt/invoice for the scooter available.

After 30 days from purchase, and within the warranty period, you will be responsible for covering the shipping cost of the scooter to our service center. The parts and labors fees will still be waived, and once the scooter has been serviced and repaired, we will ship the scooter back to you at our cost.

We also offer an option where we send replacement parts to you directly to repair your scooter from home. Please note that under warranty, the replacement part(s) is/are free. A shipping and handling fee will apply for replacement parts. The warranty covers parts and service; it does not cover shipping/handling.

Please note that the warranty for this iLiving Scooter is non-transferrable and only applies to the original owner of the iLiving Scooter. We do not provide any warranty coverage for scooters that are re-sold as we can not guarantee the quality or safety of the product.

**- CONTINUED ON NEXT PAGE -**

## WARRANTY INFORMATION

Due to safety considerations, there are a few instances in which the warranty for the iLiving Scooter will be voided. Please note that any unauthorized changes to the design of the iLiving Scooter, as well as the use of any unauthorized parts in the repair of the iLiving Scooter will void the warranty.

Further, the warranty of the iLiving Scooter does not cover any mechanical damage due to an accident, involving the scooter with property or persons, or for any mechanical damage caused by improper use of the iLiving Scooter. Proper and appropriate use of the iLiving Scooter is necessary at all times. The following pages of this User Manual will provide detailed instructions with regards to the use, operation, and maintenance of your iLiving Scooter.

# GENERAL SAFETY WARNINGS

Before you begin operating your iLiving Scooter, it is imperative that you read and understand the following health warnings, safety guidelines, and recommendations for use.

Please read and review this User Manual as often as needed.

## **IMPORTANT NOTICE - READ BEFORE OPERATING YOUR iLIVING SCOOTER**

- Every iLiving Scooter is a little bit different. Just like with a new car, please take time to familiarize yourself with your iLiving Scooter. Take in the feel of the seat and get a sense of your surroundings while sitting on the scooter. Check to see that you understand all the functions on the scooter dashboard in front of you before beginning to operate your scooter.
- We recommend that you consult a health care professional as to the adjustments on this scooter that would best suit your individual needs. Every person's body type is different. The iLiving Scooter should be adjusted to fit your individual needs and to ensure the smoothest and most comfortable ride possible.
- Before attempting to operate your new iLiving Scooter for the first time, you should take the time to read and understand how to safely operate your iLiving Scooter. If you need additional information, please contact us at any time.
- Have someone help you practice reaching, transferring to, and/or bending towards the iLiving Scooter until you are comfortable doing these actions safely on your own.
- It is important that you familiarize yourself with the areas where you plan on using the iLiving Scooter. As much as possible, check for potential hazards in these areas and learn how to avoid terrain that may be unstable or uneven. Unstable/uneven terrain will increase the risk of your iLiving Scooter tipping over.

**- CONTINUED ON NEXT PAGE -**

# GENERAL SAFETY WARNINGS

## **IMPORTANT NOTICE - READ BEFORE OPERATING YOUR iLIVING SCOOTER**

- The iLiving Scooter is intended for one person only. There should never be additional persons riding or hanging onto the scooter or armrests while the scooter is in operation.
- Do not turn the scooter ON before you are seated and ready to go.
- Do not switch the scooter ON with the throttle lever depressed.
- The scooter must be turned off by switching off the key prior to your entering or exiting the scooter.
- The weight capacity of the iLiving V8 Scooter is 275 lbs. The scooter operator and any additional items on the scooter should not exceed 275 lbs. Exceeding the weight capacity on the scooter will likely cause damage to the seat, frame, and fasteners, leading to scooter failure.
- Exceeding the weight limit will void the warranty.

Whenever your scooter is parked or idle, please power down the scooter. This action serves several purposes. By powering down the scooter, you can prevent the scooter from moving forward or backward as a result of accidental contact with the throttle lever and/or interference from EMI sources.

- It will take some time for you, the scooter operator, to become familiar with the display functions on the dashboard of the scooter as well as the sensitivity of the throttle lever when adjusting speed and slowing to a stop.
- Never attempt to go up or down stairs or escalators on your iLiving Scooter. The scooter is not designed for that sort of operation and doing so will cause severe damage to the scooter and potential injury to you.

**- CONTINUED ON NEXT PAGE -**

# GENERAL SAFETY WARNINGS

## **IMPORTANT NOTICE - READ BEFORE OPERATING YOUR iLIVING SCOOTER**

- The scooter is not designed for wheelies, exercising or stretching. Not adhering to this warning may result in injuries to yourself and bystanders.
- It may be difficult for others to see you when you are seated on your scooter. Wait until your path is clear of traffic, and then proceed with extreme caution.
- Use of safety equipment such as reflectors/reflective clothing, lights, and safety flags is advisory.
- The iLiving Scooter is not waterproof or water resistant. You should never use your iLiving Scooter in the rain or very wet surfaces. If your iLiving Scooter will be stored outdoors, please make sure that it is covered with a waterproof tarp to ensure that no water comes into contact with the electrical components of the scooter.
- DO NOT operate your scooter if it has been exposed to heavy moisture until it has been thoroughly dried out.
- ALWAYS approach small obstacles "straight on" and at slow speed.
- ALWAYS keep your feet on the scooter when driving.
- ALWAYS proceed carefully while riding, especially as you approach the downgrade of a ramp.
- DO NOT drive your scooter over deep, soft terrain (i.e. soft earth, sand, tall grass, loose gravel or snow).
- Avoid climbing or descending curbs.
- DO NOT reverse your scooter onto uneven inclines or surfaces.
- DO NOT attempt to drive on slopes with incline greater than 8 degrees. Not adhering to this warning may result in injuries to yourself and bystanders.

**- CONTINUED ON NEXT PAGE -**

# GENERAL SAFETY WARNINGS

## **IMPORTANT NOTICE - READ BEFORE OPERATING YOUR iLIVING SCOOTER**

- Contact with water can cause electrical malfunction and severely damage the scooter.
- Similarly, the iLiving Scooter was not designed for use in the snow, icy surfaces, sand, or on rocky and uneven surfaces that may damage the undercarriage of the scooter.
- If you feel that any of the wheels on the iLiving Scooter is losing traction, stop the scooter immediately. All three wheels of the iLiving Scooter must have traction in order for the scooter to perform properly. Otherwise, the scooter may lose control and risk tipping over.
- DO NOT operate the scooter with depleted batteries; you could be stranded. Check that your battery has been fully charged before riding.
- DO NOT charge the batteries and operate the scooter at the same time.
- DO NOT sit on the scooter during charging.
- Always check and unplug the charger before using the scooter.
- Used batteries must be disposed properly. Please contact your local electronic waste facility to dispose the used batteries properly.
- The best practice is to remove the battery when transporting the scooter so as not to accidentally power on the scooter which cause injuries and drain the battery.
- Do not open a battery pack by yourself. This can cause danger and loss of warranty. If you have any questions, please contact your dealer.
- DO NOT attempt to remove the seal on the side of the battery. Failure to observe this warning will invalidate your battery warranty.

**- CONTINUED ON NEXT PAGE -**

# GENERAL SAFETY WARNINGS

## **IMPORTANT NOTICE - READ BEFORE OPERATING YOUR iLIVING SCOOTER**

- DO NOT sit on your scooter while it is in a moving vehicle.
- Operate your scooter within environment temperature 5 ~ 35°C (41 ~95°F )
- Warning: DO NOT hang bags or other belonging over your steering as this may interfere with your controls. Failure to observe this warning may result in injury to yourself, bystanders, your scooter and properties.
- Prevent clothing and foreign matter goes into the wheels.
- Avoid pinch point. Keep hands and fingers clear of moving parts to avoid injury.
- Do not touch the locking of pull lever when people are sitting on the seat.
- Please make sure that the seat is properly locked and secured before sitting on the scooter.
- Uncompleted folding procedure will cause damage or injury.
- DO NOT mount or dismount your scooter unless it is switched off with the magnetic brake release disengaged - brakes locked.
- As with all electrical devices and electrically-powered vehicles, the iLiving Scooter may be susceptible to electromagnetic interference (EMI) from a variety of radio wave sources. Electromagnetic waves emitted from sources such as - but not limited to - TV stations, two-way radios, cellphones, radio stations, and "HAM" radio transmitters may cause the iLiving Scooter to move by itself, in an unintended direction, and/or cause the brakes to accidentally release or engage. These EMI sources may also permanently damage the iLiving Scooter's control system.

**- CONTINUED ON NEXT PAGE -**


# GENERAL SAFETY WARNINGS

## IMPORTANT NOTICE - READ BEFORE OPERATING YOUR iLIVING SCOOTER

- Electromagnetic interference from various sources vary in intensity as well as potential for effect on your scooter. Every electrically powered Vehicle can resist EMI sources up to a certain intensity. This means that each electrically powered vehicle has a certain "immunity" to EMI interference. The intensity of the interfering source can be measured in volts per meter (V/m). Your iLiving Scooter has an immunity level of 20V/m.
- Electromagnetic energy rapidly gains intensity as you move close to the transmitting source. As such, certain devices are of particular concern if the iLiving Scooter is used near or around these devices. EM interference from hand-held radio wave sources are usually of the highest intensity and thus, most prone to cause damage to your iLiving Scooter's control system or affect the functions of your scooter. These hand-held sources include - but are not limited to - cell phones and CB radios. It is always a good idea to turn OFF your cell phone when you are using your iLivingScooter.
- If you notice that your scooter is moving on its own or that the brakes release or engage unintentionally, power OFF your scooter immediately and check for potential sources of EMI interference.
- When driving your scooter up an incline, lean forward slightly in your seat and place your feet on the floorboard. Make sure your back is not on the backrest. This will correct your center of balance and reduce the risk of your scooter tipping over.

# LABELS AND WARNINGS


The warning labels shown below are located on different parts of the scooter. Please pay close attention to these labels. The labels are designed to help you understand how to safely and effectively use your new iLiving V8 Foldable Mobility Scooter.



Fold/Unfold Latch Label



Pinch Point Warning Label



Free Wheel Release Label



Do Not Drive Under Rain/ Snow & Weight Capacity Label



Armrest Warning Label




Maximum Incline Warning Label

## LABELS AND WARNINGS



Open Here Label



STOP Warning Label

# UNBOXING

## STEP

1



### STEP 1:

Cut the iLiving V8 Foldable Mobility Scooter's box open with a pair of scissors or a box cutter. Be sure to open the top of the box so that the scooter is sitting in the upright position.

## STEP

2



### STEP 2:

Lie the box flat on its side so the scooter wheels face the ground. The handle bars should be at the top edge of the container.

## STEP

3



### STEP 3:

Grab the scooter by the so that plastic rails on the side of the box. Remove all plastic and cardboard packaging on the scooter.

# KNOW YOUR V8 SCOOTER

## V8 SCOOTER DIAGRAM (FRONT)



## DIAGRAM LEGEND

- |          |                                 |          |                        |
|----------|---------------------------------|----------|------------------------|
| <b>A</b> | Control Console                 | <b>H</b> | Back Seat Rest         |
| <b>B</b> | Tiller - Variable Positions     | <b>I</b> | Premium Cushioned Seat |
| <b>C</b> | Tiller Height Adjustment Levers | <b>J</b> | Anti-Tip Wheels        |
| <b>D</b> | Release Lever                   | <b>K</b> | Back Tire              |
| <b>E</b> | Front Chassis Cover             | <b>L</b> | Battery                |
| <b>F</b> | Front LED                       |          |                        |
| <b>G</b> | Front Tire                      |          |                        |

# KNOW YOUR V8 SCOOTER

## V8 SCOOTER DIAGRAM(FRONT)



### DIAGRAM LEGEND

- A** Buzzer ON/OFF Switch
- B** BATTERY Lock/Unlock
- C** Front LED

# KNOW YOUR V8 SCOOTER

## V8 SCOOTER DIAGRAM(CONSOLE)



## DIAGRAM LEGEND

- |          |                        |          |                              |
|----------|------------------------|----------|------------------------------|
| <b>A</b> | Battery Status Display | <b>D</b> | Speed Control Dial           |
| <b>B</b> | Steering Wheel Handle  | <b>E</b> | Scooter Keys                 |
| <b>C</b> | Horn Button            | <b>F</b> | Speed Control Throttle Lever |

# KNOW YOUR V8 SCOOTER

## V8 SCOOTER DIAGRAM (USB/CHARGING PORT)



## DIAGRAM LEGEND

- A** Battery Charging Port
- B** USB Charging Port

# UNFOLDING THE SCOOTER

STEP  
1



**STEP 1:**

Press the Release Lever to unlock the V8.

STEP  
2



**STEP 2:**

Unfold the V8 so the Floorboard lies flat.

STEP  
3



**STEP 3:**

Fold the Seat Cushion up to lock into place.

STEP  
4



**STEP 4:**

Fold the Back Seat Rest up and you're set!

# FOLDING THE SCOOTER

**STEP  
1**



**STEP 1:**

Fold the Back-Seat Rest down against the Seat Cushion.

**STEP  
2**



**STEP 2:**

Pull the Latch lever to release lock.

**STEP  
3**



**STEP 3:**

Gently pull up by the seat cushion, and push the back wheels towards the front.

**STEP  
4**



**STEP 4:**

Latch will lock scooter in fold position.

# BATTERY INSTALLATION

## INSTALLING THE BATTERY

The iLiving Scooter battery is located at the front of the scooter. When you stand in front of the scooter, you will notice a key cover on the left side of the battery. Slid open the key cover to access the battery lock. The battery is not pre-installed inside the scooter due to safety issues during shipping.

Unlock the batteries to remove the batteries. Use the key to unlock the batteries, and slide the batteries out of the battery rails. To remove both batteries, you must slowly slide out the top battery, then the bottom respectively.

To install the battery, slowly line up the battery to the battery guiding rails, and slid the first battery all the way to the bottom. Make sure the battery is fully seated before loading the second battery. Following the same procedure, slide the second battery on top of the first one. To secure the battery, insert the key to the lock, and turn it clockwise to lock the batteries. Replace the key cover when done.



**STEP 1:**

Slide the first battery along the rail.



**STEP 2:**

Ensure the first battery is fully seated.

- STEP 3 CONTINUED ON NEXT PAGE -

# BATTERY INSTALLATION

- CONTINUED FROM PREVIOUS PAGE -

STEP  
3



**STEP 3:**

Slid the second battery along the rail until it's fully seated on top of the first battery.

STEP  
4



**STEP 4:**

Use the key to lock the batteries in place.

# CHARGING THE BATTERY

## CHARGING THE BATTERY - INDICATOR LIGHTS

Be sure to charge your scooter battery for 3 hours prior to operating your scooter for the first time. While the scooter battery is charging, the light indicator on the charger will be red. When the scooter battery is fully charged, the light indicator on the charger will turn green.



**BATTERY FULLY CHARGED**



**BATTERY IS CHARGING**

## CHARGING THE BATTERY - SCOOTER CHARGING PORT

### CHARGING THE BATTERY - SCOOTER CHARGING PORT

Charger model specification:

Model number: IN4252000

Input: AC 100-240V 50/60Hz 200VA

Output: DC 42V 2A

Note: The charger supplied with your scooter is specifically designed for the V8 Foldable Mobility Scooter battery and may not work correctly with other brand of battery. (Refer to Batteries and Battery Charging section of this manual for additional details.)

To charge the battery on your scooter, check to make sure that the battery selection switch is turned toward the battery that needs to be charged.

Next, fully insert the charge head into the scooter charging port on the scooter and insert the electrical plug into a 110/120V outlet. This scooter's AC charger has a two-prong plug that plugs directly into a 120V outlet.

**- CONTINUED ON NEXT PAGE -**

## CHARGING THE BATTERY

The charging port is located right above the left taillight. To avoid dust and dirt entering the charging port, flip the cover over the port. Use your finger to slide the cover open and closed.

Once the charging port cover is open, plug the charger head fully into the scooter's charging port securely. Next, plug the electrical head into a 120V outlet.

# CHARGING THE BATTERY

**STEP**  
**1**



**STEP 1:**

Locate the Charging Port on the back of the scooter above the left taillight.


**STEP**  
**2**



**STEP 2:**

Flip the cover of the Charging Port open. Use your finger to slide the cover aside.

**STEP**  
**3**



**STEP 3:**

Plug the Scooter Charger head into the Charging Port.

**STEP**  
**4**



**STEP 4:**

Plug the end of the Scooter Charger into an 120V electrical outlet.

# OPERATING THE SCOOTER

## CAUTION

### SEAT POSITIONING

Before operating your scooter, always make sure that the scooter seat is locked in place. Failure to do this can result in serious personal injury as well as damage to the scooter.



**INCORRECT POSITIONING**



**CORRECT POSITIONING**

When the red latch is not properly locked in place, it may look like the left image above. When this happens, the scooter seat is not locked in place.

As a result, if you were to sit in the seat and lean backwards, you and the scooter may tip over, potentially causing serious injury.

Please ensure that the red latch is flush and parallel to the frame as shown in right image above.

**- CONTINUED ON NEXT PAGE -**

# OPERATING THE SCOOTER

## OPERATING THE SCOOTER

You are now ready to begin operating your new iLiving V8 Mobility Scooter. The V8 Scooter is designed to be very user-friendly. Here are a few quick reminders to keep in mind when operating your scooter:

When driving the scooter up an incline, be sure to lean forward slightly in the seat. Do not lean backwards in the seat, as this may create an uneven distribution of weight and cause the scooter to suddenly tip over backwards.

The iLiving scooter is design with every safety precaution in mind. The scooter will automatically reduce the speed when you attempt to make a turn. This will prevent scooter from tipping over when performing abrupt sharp turns.

When operating the V8 scooter, always be sure to firmly grip the handlebars with both hands. It is never safe to operate your scooter with only one hand on the handlebars as this can lead to loss of control of your scooter. Steering the scooter requires turning the handlebars to either side. You can steer the scooter in any direction while going forward or in reverse.

It is never safe to operate your scooter while it is raining or snowing. Additionally, it is not recommended to operate your scooter on any wet or icy surface. Such conditions on the road or ground greatly increase your risk of the scooter wheels losing traction and you losing control of the scooter.

**- CONTINUED ON NEXT PAGE -**

# OPERATING THE SCOOTER

## OPERATING THE SCOOTER

Powering on your scooter requires turning the key in the ignition. This key is the same key used to lock and unlock the battery rails of your scooter.

The iLiving Scooter 's brakes will engage as soon as you release the speed lever. Familiarize yourself with these regenerative brakes by gently releasing the speed lever. This will help you gauge the rate at which the brakes engage.

In most states, it is illegal to operate a power mobility scooter on public roads. Always be alert of other motor vehicles and pedestrians on roads, parking lots, and other venues where you may be operating your scooter. Whenever operating your scooter at night, it is your responsibility to wear reflective clothing and/or reflective accessories so that cars, bicyclists, and pedestrians can quickly and easily see you in the dark. The iLiving Scooter features a pair of small headlights and a pair of red taillights. In addition, the iLiving Scooter is equipped with brake lights so that others can see when you are stopping. This is particularly useful at night or when operating your scooter in the dark or in low visibility conditions.

This iLiving Scooter is designed only for use on firm, even surfaces, such as concrete, asphalt, hardwood floors, and indoor flooring. Never attempt to operate your scooter on rough terrain, on or through sand, or in loose soil. The scooter wheels need to be able to easily retain traction with the ground - uneven surfaces can damage the scooter's body and axles, which can then cause you to lose control of your scooter.

When operating your scooter in reverse, constantly check to make sure your path is clear of obstacles.

**- CONTINUED ON NEXT PAGE -**

# OPERATING THE SCOOTER

## FREE WHEEL RELEASE SWITCH

The Freewheel Release Switch is located on the front of your iLiving Scooter. It is the red switch besides the front wheel of your scooter. When the switch is perpendicular to the ground, the scooter is in **DRIVE** mode. To unlock the freewheel release and place the scooter into **NEUTRAL** mode, simply push the switch forward.

The purpose of the freewheel release switch is to allow the scooter operator to easily push the scooter forward in the case of a dead battery or uneven terrain.

When the freewheel release, switch is pushed forward into the **NEUTRAL** position, it unlocks the wheels when the scooter is not in operation.

When the freewheel release, switch is locked into **DRIVE** mode, the scooter's wheels will not move when the scooter is turned off.



# CARE & MAINTENANCE

## SCOOTER CARE AND MAINTENANCE TIPS

- Your iLiving Scooter is designed for long-lasting performance and durability. Just like with a car, taking a few simple steps toward routine care and maintenance of your iLiving Scooter will ensure its continued performance for a longer period of time.
- Make sure the battery is fully charged, and store in a cool dry place. We recommend storing the battery on the scooter battery rails. From time to time, check to make sure that there is no corrosion on the electrode connections of the battery and the scooter.
- The seat is made from polyurethane - a durable faux leather material. It can be cleaned with any soft, non-abrasive cloth such as a washcloth. If desired, gently dampen the washcloth before cleaning the seat.
- Never wash your iLiving Scooter with a water hose or get excessive amounts of water onto the scooter when cleaning the seat. If water gets into the electrical components of the iLiving Scooter, it can critically and permanently damage the functionality of the scooter.
- Avoid moisture from coming into contact with the electrical components of the scooter, including the control panel and battery location.
- The bearings, motor, and transmission of the iLiving Scooter have been permanently lubricated and sealed at the factory. No further lubrication of these parts is necessary or advised.

- CONTINUED ON NEXT PAGE -

# CARE & MAINTENANCE

## SCOOTER CARE AND MAINTENANCE TIPS

- When checking on the overall functionality of your iLiving Scooter, there are a list of items you might consider reviewing:
  - Pay attention to whether the brakes are working properly - when you release the accelerator, the iLiving Scooter should always come to a complete stop almost immediately.
  - Make sure that the black switch governing the Freewheel Release works properly. When the switch is pulled back and perpendicular to the ground the scooter is in **DRIVE** mode. When the switch is pushed forward the scooter is in **NEUTRAL** mode.
  - Always make sure the battery compartment of the scooter is closed before operating the scooter.

# ACCESSORY INSTALLATION

## INSTALLING SCOOTER ARMRESTS

STEP  
1



### STEP 1:

Locate the red line on the armrest bar. This is the MAX width line that the armrest should be installed at.

\*(Do not install the armrest with the red line visible outside of the bracket opening)\*

STEP  
2



### STEP 2:

Insert the armrest into the bottom of the seat bracket. Adjust the width to your preference.

STEP  
3



### STEP 3:

Tighten the knob on the back of the bottom seat bracket to secure the armrest into place. Repeat for the other armrest.

# BASIC TROUBLESHOOTING

## COMMON ISSUES AND RECOMMENDED ACTIONS

### ISSUE

Scooter has no power.

### RECOMMENDED ACTION

- Make sure the key is properly inserted and turned on .
  - Make sure the battery is properly installed and is charged.
- 

### ISSUE

Scooter is turned on and battery is charged, but the scooter does not move forward or backward when I push the throttle.

### RECOMMENDED ACTION

Check to make sure that the Freewheel Release Switch is not pushed forward (**NEUTRAL**). If the Freewheel Release Switch is in the **NEUTRAL** position, pull it back to set it in DRIVE mode.

---

### ISSUE

Speed slows down dramatically while driving.

### RECOMMENDED ACTION

Battery needs to be charged - the battery may be aging and may need to be replaced.

- CONTINUED ON NEXT PAGE -

# BASIC TROUBLESHOOTING

## COMMON ISSUES AND RECOMMENDED ACTIONS

### ISSUE

Misplaced scooter key(s).


### RECOMMENDED ACTION

Contact iLiving at 800-317-1688 to order replacement key(s). Additional shipping fees apply for international orders.


# SCOOTER SPECIFICATIONS



2.2 lb  
18 V/7.8 Ah  
140W



110~240 VAC  
42V,2A





Maximum weight 275 lb



front wheel 8"



rear wheel 7"




8° maximum incline angle

colors available in:



FORWARD(High) 3.7 mph(Low) 1.8 mph  
BACKWARD(High) 1.3 mph(Low) 0.6 mph



Minimum Turning Radius 52.7"

# SUPPORT & CONTACT INFORMATION

## CONTACT US

### Phone

**Toll-free:** 1-800-317-1688  
**Local number:** 1-650-952-2257

### Email

**Customer Service:** [service@ilivingusa.com](mailto:service@ilivingusa.com)  
**Alternate:** [sales@tlmsupply.com](mailto:sales@tlmsupply.com)

### Address

iLiving USA  
860 Mahler Road  
Burlingame, CA 94010

**Like us on Facebook:**  
[www.facebook.com/ilivingusa](http://www.facebook.com/ilivingusa)

**Follow us on Twitter:**  
[@iLIVINGUSA](https://twitter.com/iLIVINGUSA)

**Visit our website:** [www.iLivingUSA.com](http://www.iLivingUSA.com)



